

Honeywell

Honeywell Process Solutions

**MasterLogic-Experion Integration
User's Guide**

**R400
March 2011**

Release R400

Honeywell

Notices and Trademarks

Copyright 2011 by Honeywell International Inc.
Release R400 – March 2011

While this information is presented in good faith and believed to be accurate, Honeywell disclaims the implied warranties of merchantability and fitness for a particular purpose and makes no express warranties except as may be stated in its written agreement with and for its customers.

In no event is Honeywell liable to anyone for any indirect, special or consequential damages. The information and specifications in this document are subject to change without notice.

Experion PKS is a registered trademark of Honeywell International Inc.

Other brand or product names are trademarks of their respective owners.

Honeywell Process Solutions
1860 W. Rose Garden Lane
Phoenix, AZ 85027 USA
1-800 822-7673

About This Document

This document describes how to integrate the MasterLogic 200R/200 IEC with Experion Process Knowledge System. The guide describes the installation, configuration, operations, and troubleshooting tasks associated with the MasterLogic PLC - Experion integration. The term PLC used throughout this document refers to MasterLogic PLC. The MasterLogic PLC - Experion integration discussed in this guide is tested with ML200 IEC / ML200R and Experion R400.

Intended Audience

The intended audiences for this guide include:

- Project Engineers.
- Operators.
- Service Engineers.

Prerequisites for using this guide

Before you begin, ensure that you are familiar with the following information.

- Experion concepts and Quick Builder usage



REFERENCE – EXTERNAL

- For details about Experion, see [Experion Knowledge Builder > Experion PKS R400 > Purpose > Overview > Introduction > Experion Process Knowledge System](#).
- For details about Quick Builder features and operations, see [Experion Knowledge Builder > Experion PKS R400 > Configuration > Quick Builder Guide](#).

-
- PLC concepts and SoftMaster tool usage.



REFERENCE - EXTERNAL

For details about PLC concepts and SoftMaster tool usage, see [SoftMaster User Guide](#) and [PLC User Guide](#).

About This Document
How to use this guide

How to use this guide

Here is a list of topics covered in this guide:

Topic
Introduction
Installing ML Server
MLServer License
Configuration
Troubleshooting

References

The following list identifies references for material discussed in this publication:

Experion Knowledge Builder

Acronyms and Definitions

The following section describes some commonly used industry-wide and Honeywell-specific terminology:

Terminology	Description
MLServer	MasterLogic Server software which interfaces MasterLogic PLC with Experion.
MLPLC	MasterLogic Programmable Logic Controller.
PLC	Programmable Logic Controller.
PV	Process variable parameter of a standard Point.
QDB	Quick Builder project file containing one or more Channels, Controllers and Points.
SM	SoftMaster PLC monitoring tool.
MLDP	MasterLogic Dedicated Protocol supported by ML200/ML200R.
RTC	Real Time Clock data represents the current time in the PLC.
SP	Set point parameter for the Experion Analog point.
OP	Output parameter for the Experion Analog / Status point.
SCADA	Supervisory Control and Data Acquisition

Contacts

World Wide Web

Honeywell Organization	WWW Address (URL)
Corporate	http://www.honeywell.com
Process Solutions	http://www.honeywell.com/ps

Telephone

Contact Honeywell by telephone at the following numbers listed:

Location	Organization	Phone
United States and Canada	Honeywell IAC Solution Support Center	1-800-822-7673
Europe	Honeywell TAC-EMEA	+32-2-728-2704
Pacific	Honeywell Global TAC - Pacific	1300-300-4822 (toll free within Australia) +61-8-9362-9559 (outside Australia)
India	Honeywell Global TAC - India	+91-20-2682-2458 / 1600-44-5152
Korea	Honeywell Global TAC - Korea	+82-2-799-6317
People's Republic of China	Honeywell Global TAC - China	+86-10-8458-3280 ext. 361
Singapore	Honeywell Global TAC - South East Asia	+65-6580-3500
Taiwan	Honeywell Global TAC - Taiwan	+886-7-323-5900
Japan	Honeywell Global TAC - Japan	+81-3-5440-1303
Elsewhere	Call your nearest Honeywell office.	

Symbol Definitions

The following table lists the symbols used in this document to denote certain conditions:

Symbol	Definition
	ATTENTION: Identifies information that requires special consideration.
	TIP: Identifies advice or hints for the user, often in terms of performing a task.
	REFERENCE -EXTERNAL: Identifies an additional source of information outside of the bookset.
	REFERENCE - INTERNAL: Identifies an additional source of information within the bookset.
	CAUTION: Indicates a situation which, if not avoided, may result in work (data) on the system being damaged or lost, or may result in the inability to properly perform the process.
	WARNING: Indicates a potentially hazardous situation, which, if not avoided, could result in serious injury or death.

About This Document
Symbol Definitions

Contents

1. INTRODUCTION	13
1.1 Overview	13
MasterLogic PLC - Experion integration solution	13
Integration scope.....	14
MasterLogic PLC-Experion integration elements	15
Supported MasterLogic PLCs	19
2. INSTALLING ML SERVER	21
2.1 Installing ML Server in Experion Server	21
MLServer media.....	21
Installing MLServer	21
Verifying MLServer installation.....	23
2.2 Installing in Client machines.....	27
Overview	27
Prerequisites for installing MLServer.....	27
MLServer media.....	27
Installing MLServer	27
Verifying MLServer installation.....	29
2.3 Getting started.....	30
Configuring MasterLogic PLC - Experion integration	30
2.4 Removing MLServer	31
Using Add/Remove programs	31
Using MLServer.exe in the installation CD	32
2.5 Repairing MLServer	33
Using MLServer.exe in the installation CD	33
3. MLSERVER LICENSE	35
3.1 Overview	35
Background.....	35
Before you begin	35
Obtaining the license.....	35
Using the demo versions of MLServer	35
MLServer license features.....	36
Experion point and PLC point.....	36
3.2 Obtaining a new license	37

Contents

Obtaining a new license through e-mail	37
Installing license certificate	39
3.3 Updating license certificate	41
Updating license certificate	41
3.4 Transferring license certificate	45
Terminating license certificate	46
Transferring license certificate	47
4. CONFIGURATION	49
4.1 Overview	49
Configuring MasterLogic server	49
4.2 Configuring MLServer using Configuration Tool	50
MLServer Configuration Tool	50
Configuring PLC Information	52
Configuring PLC Log information	55
Configuring MLServer advanced information	57
Adding a new PLC	59
Deleting a PLC	62
Configuring MLServer general information	63
4.3 Configuring MLServer using Quick Builder	65
Overview of Quick Builder components	65
Configuring the Quick Builder component manager	65
Configuring a MasterLogic Channel	67
Configuring a MasterLogic Controller	70
Configuring an Experion Point (Analog and Status)	72
PLC Point configuration details	80
Defining data formats	88
4.4 Downloading Quick Builder Points to Experion	92
Overview	92
4.5 Verifying the configuration	93
Overview	93
Verifying data exchange between PLC and Experion	93
5. MONITORING PLC STATUS FROM EXPERION DISPLAYS... 101	
5.1 Overview	101
Experion displays	101
5.2 Building a Point in Experion corresponding to the PLC	102
Using Configuration tool	102

5.3	Using Experion custom displays.....	105
	PLC System Status Display	105
	Config Info.....	105
	Status Info.....	109
	Driver Info.....	119
5.4	Using Experion standard Station displays.....	125
	Channel Summary page	125
	Point Detail display.....	126
5.5	Monitoring PLC displays from an Experion client system	127
	Overview	127
5.6	Bad quality items	129
	Overview	129
	Viewing bad quality item in Point Detail display	130
6.	ALARMS AND EVENTS INTEGRATION.....	135
6.1	Alarm integration	135
	Types of Alarms	135
	Viewing PLC alarms in Experion Station.....	136
	Sample alarms raised in Experion.....	137
6.2	PLC Events	138
	Types of PLC events.....	138
	Transferring PLC events to Experion/Log files	138
	Transferring SOE events from PLC to Experion Station	141
7.	TROUBLESHOOTING	145
7.1	MasterLogic Server logs	145
	Overview	145
	MLServer logs.....	145
	ML protocol logs.....	146

Contents

1. Introduction

1.1 Overview

MasterLogic PLC - Experion integration solution

The MasterLogic PLC-Experion integration solution unifies the MasterLogic PLCs with Experion. The solution enables Experion to read/write PLC data and monitor PLC alarms and events from Experion Station. The solution is achieved by connecting PLCs to Experion server through FTE and mapping PLC data items to standard Experion Points.

The following figure illustrates the integration solution:




Figure 1.1-1: MasterLogic PLC - Experion Integration Architecture

The PLC can also be connected directly to the system installed with SoftMaster.

Redundancy is implemented at three different levels:

1. **Redundant PLC** – Redundancy in PLC can be achieved using many methods:
 - Having two FENET modules within the same PLC.
 - Having redundant CPUs.
 - Having redundant IO Modules or Bases, and so on.

1. Introduction

1.1. Overview

- The underlying principle is that when the master module fails, the standby module takes over the control without interrupting the operation of the process in control.
- 2. **FTE Network** – Two Ethernet cables are connected between the Experion and the PLC or other devices. When the master network connection fails, the standby network connection is used for the communication between the Experion and the PLC.
- 3. **Redundant Experion PKS server** – The secondary Experion server takes over when the primary Experion server fails. All the MasterLogic Channels, Controllers, Points and Graphics are also available when the secondary Experion server is active.



ATTENTION

The MasterLogic PLC functions as a non-FTE node together with other FTE nodes on the network.

Integration scope

Experion integration gains special access to intricate areas of MasterLogic PLC through proprietary MLDP:

- Direct variables (%I Input image, %Q Output image, %M internal Memory variables)
- %R File Register variables (non-volatile memory variables – data retention)
- CPU, I/O module, communication Status and Alarms Flags (CPU error, battery error, I/O module)
- Real Time Clock (RTC) areas
- I/O Configuration parameters
- PLC History Logs (Error, Activity, Mode changes, Power shutdown)
- DISOE module integration

MasterLogic PLC-Experion integration elements

SoftMaster

The SoftMaster tool is used for the following:

- Writing ladder logic programs which contain the engineering logics
- Monitoring the PLC values and/or force values into PLC.

The following figure depicts the **Address Monitoring** window (available only in SoftMaster):




Figure 1.1-2: Address monitoring window

1. Introduction

1.1. Overview

Quick Builder

Quick Builder is the tool used for the following:

- Configuring MasterLogic Channel, MasterLogic Controller, and Analog and Status Point.
- Uploading/downloading Channel, Controller, and Point from/to the Experion server. The downloaded items are stored in the Experion server database.

Experion Station

Experion station is used for the following:

- Monitoring the online status of PLCs integrated with Experion as Alarms/Events or through Custom graphics.
- Change the online status of MasterLogic Controllers and MasterLogic Channels.
- View the point values obtained from Experion through custom graphics.

Experion has the following two types of stations:

Flex Station – This is generally installed on a computer other than the server computer.

Console Station – Console Station has direct access to the Process Controllers, as well as the Experion server.

MasterLogic PLC

MasterLogic PLC performs the following:

- Replaces the necessary sequential relay circuits for machine control.
- Used in any application that needs some type of electrical control.
- Operates by looking at its inputs and depending on their state, turning on/off its outputs.
- Current MasterLogic PLCs available are ML200 IEC and ML200R.

The high speed Ethernet communication modules (FEnet) of MasterLogic-200 system reside as non FTE nodes on FTE network providing a high-level interface with Experion servers.

MLDP (MasterLogic Dedicated Protocol) server embedded in the FENET modules offer Experion servers, a special proprietary access on TCP-IP layer to various memory variables of the PLC CPU.

MasterLogic Server

The PLCs are integrated to Experion server, through the MLServer software. After downloading the Points to Experion server, MLServer performs the following:

- Starts communicating with PLCs.
- Reads PLC information and writes to the Experion server.
- Writes values from the Experion server to PLCs.
- Transfers system status, IO module information, alarms/events associated with PLCs to Experion server which can be monitored via the Experion Station.

Experion Server

The Experion is a standard distributed control system that provides plant-wide control. The Experion server contains supervisory control functions, the Experion Global Data infrastructure and optional redundancy. The server hosts graphical tools such as Control Builder and HMIWeb Display Builder and acts as the central repository for all system data. It also runs all the core system functions, including:

- Data acquisition and processing
- Alarm and event management

The following picture illustrates the software architecture of the MasterLogic PLC-Experion integration solution.

1. Introduction
1.1. Overview




Figure 1.1-3: Components of MasterLogic PLC – Experion Integration solution

Supported MasterLogic PLCs

The supported PLCs are:

- ML200R
- ML200 IEC

ML200R

These are Honeywell's next generation Programmable Logic Controllers that support CPU-level redundancy. It provides real power, performance and versatility with a compact size, high speed scanning of I/O Channels, and execution of program instructions. It also provides open network through Ethernet, ProfibusTM-DP, DeviceNetTM, remote I/O, and engineer-friendly programming and diagnostic software tools.

ML200

Honeywell's next generation Programmable Logic Controllers providing real power, performance and versatility with compact size, high speed scanning of I/O Channels and execution of program instructions, open network through Ethernet, ProfibusTM-DP, DeviceNetTM, remote I/O and engineer-friendly programming and diagnostic software tools.

1. Introduction

1.1. Overview

2. Installing ML Server

2.1 Installing ML Server in Experion Server

This section describes the procedure for installing the MLServer.

- Install Experion server with OPC client license. (The MLServer information provided in this guide is compatible with Experion R400.)
- Install MS-XML version 6.
- Have Administrative privileges to log into the Experion server machine.



REFERENCE - EXTERNAL

For more details on hardware and software requirements, refer to [Hardware and Software requirements section in Experion Knowledge Builder](#).



ATTENTION

You must have Experion OPC client license (Model#: EP-OPCCLI) to configure MasterLogic Channel, Controller, and Point.

MLServer media

The MLServer CD contains the MLServer.exe file required to install the MLServer.

Installing MLServer

To install MLServer, perform the following steps:

Step	Action
1	Click MLServer.exe in the MLServer installation CD.
	 ATTENTION If an earlier version of MLServer is installed already, the wizard displays an error message indicating that the previous MLServer version must be removed before installing the new version.
	After performing the initial checks, the wizard displays the welcome screen.
2	Click Next . The wizard displays the License Agreement screen.

2. Installing ML Server

2.1. Installing ML Server in Experion Server

Step	Action
3	Select I accept the terms in the license agreement .
4	Click Next . The wizard displays the Destination Folder screen.
5	Click Next . OR Click Change to select a different folder.
<hr/>	
	 TIP Honeywell recommends retaining the default destination folder for installing MLServer.
<hr/>	
	The wizard displays the Ready to Install the Program screen.
6	Click Install . The wizard displays the Installing Honeywell – MasterLogic Server screen, displaying the status messages and the progress bar during the installation process.
7	The wizard completes the installation and displays the Install Shield Wizard Completed screen:
8	Click Finish to close the wizard.
	 ATTENTION MLServer installer displays an error message "Error opening Installation log file. Verify that the specified log file location exists and is writeable". This occurs if Experion is not installed in the machine or if the installer is not run with administrator privileges. Click OK . If the Experion server is installed, run MLServer installer with administrator privileges else install Experion server with OPC client license and install MLServer again.

Verifying MLServer installation

Verification of MLServer installation involves the following:

Verify graphics pages and xml files copied to the installation path
(*C:\ProgramData\Honeywell\Experion PKS\Client\Abstract*) during installation, as displayed in the following figure.




Figure 2.1-1: Graphics pages and xml files copied during installation

2. Installing ML Server

2.1. Installing ML Server in Experion Server

The following table lists the graphics pages and xml files copied during installation:

Type	Filename	Description
xml files	MLConfig.xml	This file contains the PLC specific configuration.
	MLMonitor.xml	This file contains common settings for the MLServer and the Graphics.
	MLSOEConfig.xml	This file contains SOE configuration for all PLCs.
Graphics pages	MLPLC_Config.htm	This Experion graphics page displays the base slot information of the PLCs.
	MLPLC_Status.htm	This graphics page displays the PLC status information.
	MLPLC_Driver.htm	This Experion graphics page displays the MLServer (Driver) diagnostics information.
Schema files	MLConfig.xsd	XML schema file for MLConfig.xml
	MLMonitor.xsd	XML schema file for MLMonitor.xml
	MLSOEConfig.xsd	XML schema file for MLSOEConfig.xml

Verify xml, exe, dll files and document copied to the installation path (typically **C:\Program Files\Honeywell\MasterLogicServer**) during installation, as shown in the following figure:

2. Installing ML Server

2.1. Installing ML Server in Experion Server




Figure 2.1-2: Files copied during installation

The following table lists the xml file, user guide and the template file copied during installation:

Type	Filename	Description
xml file	MLAppSettings.xml	This file is used for configuring the MasterLogic server application settings.
Schema files	MLAppSettings.xsd	XML schema file for MLAppSettings.xml.
Document	MLServer_User's_Guide.pdf	This user's guide describes how to integrate the MasterLogic 200R/200 IEC with Experion Process Knowledge System.
Template	StatusPointBuildTemplate.txt	This is the template file for Point building.
Configuration Tool	MLServerConfigTool.exe	This utility is used for configuring the PLC information and other information for the

2. Installing ML Server

2.1. Installing ML Server in Experion Server

Type	Filename	Description
		MlServer.
Point Build Utility	PointBuildUtility.exe	This utility is used for building the Point corresponding to the PLC and the parameters associated with the Point.
License Application	MlServerLicenseRegistration.exe	This application is used for obtaining a new license, update, terminate and transfer the license.
Demo certificate	MlPLC_Demo.cer	This is a demo certificate file for MlServer for 100 PLC points.
QDB file	Ml_Sample.qdb	This file contains sample ML Channel, ML Controller and sample Analog/Status Points.

The MlServer configuration tool, user's guide and the license application is accessed through **Start > Programs > Honeywell MasterLogic Server**. The shortcut for the Configuration tool is available on the desktop.




Figure 2.1-3 Shortcuts to MlServer utilities

2.2 Installing in Client machines

Overview

This section describes the procedure for installing the MLServer in Client machines

Prerequisites for installing MLServer

Following are the prerequisites.

- Ensure that you have installed Experion R400 Client (Console/ Flex).
- Ensure that you have logged into the Experion Client machine with Administrative privileges.

MLServer media

The MLServer CD contains the MLServer.exe file required to install MLServer.

Installing MLServer

To install MLServer, perform the following steps:

Step	Action
1	Click MLServer.exe in the MLServer installation CD.
	 ATTENTION If an earlier version of MLServer is installed already, the wizard displays an error message indicating that the previous MLServer version must be removed before installing the new version.
	After performing the initial checks, the wizard displays the welcome screen.
2	Click Next . The wizard displays the License Agreement screen.
3	Select I accept the terms in the license agreement .
4	Click Next . The wizard displays the Destination Folder screen.
5	Click Next . OR Click Change to select a different folder.

2. Installing ML Server


2.2. Installing in Client machines

Step	Action
	 TIP Honeywell recommends retaining the default destination folder for installing MLServer.
	The wizard displays the Ready to Install the Program screen.
6	Click Install . The wizard displays the Installing Honeywell – MasterLogic Server screen, displaying the status messages and the progress bar during the installation process.
7	The wizard completes the installation and displays the Install Shield Wizard Completed screen:
8	Click Finish to close the wizard.
	 ATTENTION MLServer installer displays an error message "Error opening Installation log file. Verify that the specified log file location exists and is writeable". This occurs if Experion is not installed in the machine or if the installer is not run with administrator privileges. Click OK . If the Experion client is installed, run MLServer installer with administrator privileges else install Experion client and install MLServer again.

Verifying MLServer installation

Verify dll files copied to the installation path (typically C:\Program

Files\Honeywell\MasterLogicServer) during installation, as displayed in the following figure.



2. Installing ML Server

2.3. Getting started

2.3 Getting started

Configuring MasterLogic PLC - Experion integration

After installation, the following tasks are performed:

Step	Action
1	Installing one or more Ethernet modules (EUTB/FENET) in each PLC. Connecting the Ethernet modules to the Experion server through Ethernet cables.
2	Configuring the IP Addresses of these modules using the SoftMaster tool. Ping the IP Address from the Experion server for verifying the communication between the PLC and the Experion server.
3	Obtaining the license.
4	Configuring MLServer using Configuration Tool.
5	Verifying data exchange between PLC and Experion.

2.4 Removing MLServer



ATTENTION

- After removing the MLServer, the integration between the PLC and the Experion does not work.
 - The MLServer must be removed only if the software is upgraded.
 - Ensure that the MLServer is stopped before removal.
 - Back up the xml files before performing the removal.
-

Using Add/Remove programs

To remove MLServer, perform the following steps:

Step	Action
1	Click Start > Settings > Control Panel .
2	Double-click Add/Remove Programs . The Add/Remove Programs window appears.
3	Select MLServer <Version> and click Remove .
4	Click Yes . The wizard displays Remove the Program screen.
5	Click OK . The wizard displays the MLServer <Version> screen, displaying the status messages and the progress bar while the remove operation is in progress.

2. Installing ML Server

2.4. Removing MLServer

Using MLServer.exe in the installation CD

To remove MLServer using the MLServer.exe file in the installation CD, perform the following steps:

Step	Action
1	Click MLServer.exe in the installation CD. The Program Maintenance screen appears.
2	Click Remove and then Next . The Remove the Program screen is displayed.
3	Click Remove . The MLServer is successfully removed. There is no explicit message displayed on completion of removal.

2.5 Repairing MLServer

Using MLServer.exe in the installation CD

The MLServer application can be repaired to fix the installation errors. The missing or corrupt files, shortcuts, and registry entries can be fixed using this option.

To fix the installation errors, perform the following steps:

Step	Action
1	Click MLServer.exe file in the installation CD. The Program Maintenance screen appears.
2	Select Repair and click Next .
3	Click Repair . The installation errors are successfully repaired. There is no explicit message displayed on completion of repair.

2. Installing ML Server
2.5. Repairing MLServer

3. MLServer License

3.1 Overview

Background

After installing the MLServer, you must register and obtain the license prior to using it.

Before you begin

Before obtaining the license, ensure that you have the following items:

- Voucher ID – This is provided by Honeywell when you purchase the MLServer.
- Host ID Files – These files are automatically created when you open the MLServer License Registration Application or enable the ML Channel for the first time. Names of the Host ID files are <Computer Name>.Zip and <Computer Name>.HID, example: If the computer name is EPKSSRVRPC1 then the Host ID files created are EPKSSRVRPC1.zip and EPKSSRVRPC1.HID. These files are available in the installation path (typically C:\Program files\Honeywell\MasterLogicServer).

Obtaining the license

Request by email – Send an e-mail to License.Server@honeywell.com attaching the Host ID files that is <Computer Name>.Zip and <Computer Name>.HID and mentioning the voucher ID to obtain the license.



ATTENTION

- Separate e-mail needs to be sent for getting license for each Experion server attaching the Host ID files of the corresponding computer.
 - For a redundant Experion server two licenses must be obtained, one for each server machine.
-

Using the demo versions of MLServer

The license certificate for the demo version of MLServer is automatically created and activated when the MLServer is installed. The demo version of MLServer allows configuring 100 Points and there is no restriction on the number of PLCs. There is no validity period for the demo license.

3. MServer License

3.1. Overview



ATTENTION

After obtaining the original license, the demo license of MServer is replaced with the original license.

MServer license features

The following two features are licensed for MServer:

- Number of PLCs
- Number of PLC points that can be used across all the PLCs

For example, if the obtained license supports 10 PLCs and 1000 PLC points,

- The MServer communicates with a maximum of 10 PLCs.
- A maximum of 1000 PLC points can be used for data communication across all the PLCs.

Experion point and PLC point

Experion Analog/Status points are configured using the Quick Builder in the MasterLogic Controllers for data communication with the PLC. The PLC points defined within these Experion points provide a way of addressing the location in PLC where the values are stored.

3.2 Obtaining a new license

Obtaining a new license through e-mail



ATTENTION

You must be a member of Product Administrators group to obtain the new license. If not, perform the following steps:

1. Choose **Start > Programs > Honeywell MasterLogic Server**.
 2. Right-click License Registration.
 3. Select Run as administrator.
-


The process of obtaining a new license through e-mail involves the following steps:

Step	Action
1	Obtain the voucher ID from Honeywell.
2	Create the Host ID files by opening the MServer License Registration Application or enable the ML Channel for the first time.

3. MLServer License

3.2. Obtaining a new license

Step	Action
3	<p>Send an e-mail to License.Server@honeywell.com with the following details:</p> <ul style="list-style-type: none">In the Subject line, type the voucher ID as – VOUCHID :< voucher ID>. For example, type – VOUCHID: MLPLC_1PLC_50POINTS.Attach the Host ID files that is <Computer Name>.zip and <Computer Name>.HID files.



ATTENTION


- The Subject line is case-sensitive.
 - Other than the Subject line, do not type any information in the e-mail.
-
- After receiving the e-mail, Honeywell sends the new license certificate in a zip file. This file must be unzipped using the password, **password**.
- 4 Save the license certificate in the MLServer system. This license certificate can be re-installed if the Experion server machine is reformatted.
-

Installing license certificate

To install the new license certificate received from Honeywell, perform the following steps:

- | Step | Action |
|------|--|
| 1 | Click Start > Programs > Honeywell MasterLogic Server > License Registration .

The MLServer License Registration dialog box appears. |
| 2 | Click Browse to select the license certificate received from Honeywell. |




3. MLServer License

3.2. Obtaining a new license

Step	Action
------	--------

- The selected license certificate appears in **Certificate file path** as shown in the following figure:



- 3 Click **OK**.

The **MLServer License** dialog box appears displaying the licensed number of PLCs and PLC points.



ATTENTION

The license need not be terminated before uninstalling MLServer software. The license is retained and active when the MLServer software is re-installed in the same machine.

3.3 Updating license certificate

Updating license certificate

The updated license certificate can be received from Honeywell with additional features (like more number of points). After installing the license certificate on an Experion server, the features including the number of points are updated.

To update the license certificate, perform the following steps:


Step	Action
1	Obtain the new voucher ID (supersede of the original voucher) from Honeywell.
2	Send an e-mail to License.Server@honeywell.com with the following detail: <ul style="list-style-type: none">In the Subject line, type the voucher ID as – VOUCHID :< voucher ID>. For example, type – VOUCHID: MLPLC_1PLC_50POINTS _Supersede.Attach the Host ID files that is <Computer Name>.zip and <Computer Name>.HID files.
	 ATTENTION <ul style="list-style-type: none">The Subject line is case-sensitive.Other than the Subject line, do not type any information in the e-mail.
	<ul style="list-style-type: none">After receiving the e-mail, Honeywell sends the new superseded license certificate in a zip file. This file must be unzipped using the password, password.
3	Save the license certificate in the MServer system. This license certificate can be re-installed if the Experion server machine is reformatted.
4	Choose Start > Programs > Honeywell MasterLogic Server > License Registration .

3. MLServer License

3.3. Updating license certificate

Step	Action
------	--------

- The **MLServer License** dialog box appears.



- 5 Click **Supersede License**.

The **Enter Password** dialog box appears.



- 6 Type the password as mlplcr400 and click OK.



ATTENTION

If the MLServer version is R4xx, use mlplcr400 as password.

- 7 Click **Yes** to continue.
-

Step	Action
• The Re-license MLServer dialog box appears.	
8 Click Browse to select the new license certificate.	
9 Select the file and click Open .	
• The selected certificate appears in New certificate file path as shown in the following figure:	

3. MLServer License

3.3. Updating license certificate

Step	Action
10	<p>Click OK.</p> <ul style="list-style-type: none">The following message box appears. 
11	<p>Click OK.</p> <p>The MLServer License Registration dialog box appears displaying the superseded license features.</p>
12	<p>Restart MLServer for the new license to take effect.</p>

3.4 Transferring license certificate

The process of transferring the license certificate from one Experion server to another involves the following tasks:

- Terminate the license certificate on the first Experion server.
- Install the license certificate on the new Experion server.



CAUTION

If the license is terminated, it cannot be re-installed in the same machine. To re-install the license the machine must be formatted.


3. MLServer License

3.4. Transferring license certificate

Terminating license certificate

To terminate the license certificate, perform the following steps on the first Experion server:

Step	Action
1	<p>Click Start > Programs > Honeywell MasterLogic Server > License Registration.</p> <ul style="list-style-type: none">The MLServer License dialog box appears.





- Click **Terminate License**.
The **Enter Password** dialog box appears.
- Type the password as mlplcr400 and click OK.



ATTENTION

If the MLServer version is R4xx, use mlplcr400 as password.

Step	Action
	<ul style="list-style-type: none"> The following message box appears. 
4	<p>Click Yes to continue.</p> <ul style="list-style-type: none"> The license is terminated and the following message appears. 



ATTENTION

The *.term file generated after terminating the license can be used for transferring the license to a different machine.

Transferring license certificate

To transfer the license certificate to a different Experion server, perform the following steps:

Step	Action
1	Create the Host ID files by opening the MLServer License Registration Application or enable the ML Channel for the first time.
2	<p>Send an e-mail to License.Server@honeywell.com with the following details:</p> <ul style="list-style-type: none"> In the Subject line, type the voucher ID as – VOUCHID :< voucher ID>. For example, type – VOUCHID: MLPLC_1PLC_50POINTS. Select the <Computer Name>.HID and the termination certificate (*.term) files and create a zip file with the password, password. Attach this zip file to the e-mail.
Note: Ensure not to select the option to save the folder information while	

3. MLServer License

3.4. Transferring license certificate

Step	Action
	zipping the files.
	 ATTENTION <ul style="list-style-type: none">• The Subject line is case-sensitive.• Other than the Subject line, do not type any information in the e-mail.
4	• After receiving the e-mail Honeywell sends the new license certificate in a zip file. This file must be unzipped using the password, password . Save the license certificate in the MLServer system. This license certificate can be re-installed if the Experion server machine is reformatted.
5	Install the new license certificate.
	 REFERENCE – INTERNAL For more details about installing the new license certificate, see Installing license certificate .

4. Configuration

4.1 Overview

Configuring MasterLogic server

To communicate with the PLCs, the MLServer must be configured with PLC information. This configuration involves the following tasks:

- Configuring MLServer using Configuration Tool
- Configuring MLServer using Quick Builder
- Downloading Quick Builder Points to Experion

The following diagram depicts the configuration of MLServer:




Figure 4.1-1: MasterLogic Server configuration

4. Configuration

4.2. Configuring MLServer using Configuration Tool

4.2 Configuring MLServer using Configuration Tool

MLServer Configuration Tool

The PLC information must be configured for the MLServer using the MLServer Configuration Tool. The PLC information like PLC Name, Id, Type, IP Address, and Logs are configured for each PLC in the plant. The tool consists of the following tabs:

- PLC
- LOGS
- ADVANCED



ATTENTION

The PLC information configured using the configuration tool must be saved.

The MLServer must be restarted for the changes to take effect. However, the exception is that when the MLServer or Protocol Log file settings are changed, there is no need to restart the MLServer.

To configure the PLC information, perform the following steps:


Step	Action
1	Choose Start > Programs > Honeywell MasterLogic Server > Configuration Tool . The following window appears.

4. Configuration

4.2. Configuring MLServer using Configuration Tool

Step

Action



By default, the PLC **ML01** appear in the window.

Note: The first PLC is selected in the tool.

- 2 [Configuring PLC Information.](#)
- 3 [Configuring PLC Log information.](#)
- 4 [Configuring MLServer advanced information](#)
- 5 Click **Save Configuration**.

The configuration is saved successfully:

- 6 Click **OK**.
-

4. Configuration

4.2. Configuring MLServer using Configuration Tool

Step	Action
------	--------

7 Repeat steps 1 through 7 for each PLC in the plant.

Note: The PLCs must be added using the procedure [Adding a new PLC](#).



Tip

The ToolTip appears when the cursor is placed over the options available in the MLServer Configuration tool. The ToolTip provides additional information about the setting options.

Configuring PLC Information

The PLC tab in the configuration tool is used for the following purposes:


- Configuring the general PLC information used by MLServer to communicate with the PLC.
- Enabling/Disabling the IO Read and other features within the MLServer.

To configure the PLC information, perform the following steps:

Step	Action
------	--------

1 Select the PLC ID from the left pane.

The PLC information appears in the **PLC** tab as shown in the following figure.



Step	Action
3	<p>Enter PLC Name.</p> <p>Note: The PLC Name is a unique name for each PLC. It is alphanumeric and there is no limit on the number of characters. Example – MLPLC1. Separate logs are created for each PLC based on the PLC ID.</p>
4	<p>Select the PLC type from the PLC Type list box</p> <p>Note: The supported PLCs are ML200-IEC and ML200R.</p>
5	<p>Enter the EPKS Asset Name for this PLC. All the Alarms/Events raised by the MLServer are in this asset.</p>
	<p> REFERENCE – EXTERNAL</p> <p>For more details on configuring and creating asset, refer Experion Knowledge Builder > Experion R400 > Configuration > Enterprise Model Builder User's Guide > Accessing Enterprise Model Builder > Creating and Configuring Assets.</p>
6	<p>Enter IPAddress1, IPAddress2, IPAddress3 and IPAddress4.</p> <p>Note:</p> <p>IPAddress1- Represents the primary PLC's IP address in Primary Network.</p> <p>IPAddress2- Represents the secondary or redundant PLC's IP address in Primary Network.</p> <p>IPAddress3- Represents the primary PLC's IP address in Secondary Network, in case of dual network.</p> <p>IPAddress4- Represents the secondary or redundant PLC's IP address in Secondary Network, in case of dual network.</p> <p>The MLServer searches for a valid PLC connection in the following sequence: IP Address1, 2, 3 and 4.</p>
7	<p>To view PLC status information in the Experion graphics display select Status Read and EPKS Write check boxes in Monitor.</p>
8	<p>To view IO module information in the Experion graphics display select IO Read and EPKS Write check boxes in Monitor.</p>
9	<p>Auto Point Build check box is used for building the ML points. It must be enabled to use the PLC.</p> <p>If any PLC is configured and not used, then disable the check box.</p>

4. Configuration

4.2. Configuring MLServer using Configuration Tool

Step	Action
10	To view PLC status Alarms / Messages in the Experion Alarm summary display select Status Read and Alarm Raising check boxes in Monitor .
11	To view the updated RTC time in Experion graphics display select Enable Read/Write in RTC and EPKS Write under Monitor . Enable Read/Write If Yes , it allows MLServer to read/write RTC time from/to PLC. Synch Interval Indicates the time frequency for reading the RTC time from the PLC and updating in Experion. Note: If this value is 0 then the RTC time is not read or written from/to the PLC. Deadband The value set for Deadband under RTC indicates the difference in time between the PLC and System Time beyond which the RTC time is written to the PLC. The PLC time is updated with the Experion system time, if the time difference is equal to or greater than RTC Deadband. Note: If this value is 0 then the RTC time is not written to the PLC.
12	To view PLC related alarms like MLServer Licensing Alarms, PLC connection and disconnection in the Alarm summary display, select Alarm Raising check box under Monitor .


Configuring PLC Log information

The **LOGS** tab in the configuration tool is used for the following purposes:

- Configuring settings for transfer of the PLC Logs into the MLServer
- Enabling/Disabling the PLC level MLServer and Protocol logs

To configure the PLC log information, perform the following steps:

Step	Action
1	Select the PLC ID from the left pane and click LOGS tab.



- 2 Select the **Initial History** check box if the already existing events in the PLC Log need to be transferred to Experion server or Log files during startup of the MLServer.

Note: Honeywell recommends that this option need not be selected.

- 3 Select the **Log To File** check box if the events in the PLC Log need to be transferred to corresponding MLServer log files.

Note: Honeywell recommends that this option need not be selected.

4. Configuration

4.2. Configuring MLServer using Configuration Tool

Step	Action
4	Select the Events check box if the events in PLC Log need to be transferred to Experion server as Events/Alarms. Note: Honeywell recommends that this option can be selected for the desired PLC log.
5	The Event Category selection indicates whether the event needs to be transferred to Experion as Alarms or Events. The possible values are System Alarm and System Event. Note: Honeywell highly recommends that the default System event setting must not be changed.
6	Click  under MLServer Logs to browse and select the folder path to save the MLServer log files.
7	Click  under Protocol Logs to browse and select the folder path to save the Protocol log files.
8	Select Request, Response, Trace and Monitor under MLServer Logs to enable the generation of corresponding logs.
9	Select Request, Response, Trace and Hex under MLServer Logs to enable the generation of corresponding logs.



ATTENTION


Honeywell recommends not enabling Hex log as the Hex logs need more disk space and reduce the overall system performance.

Configuring MLServer advanced information

The **ADVANCED** tab in the configuration tool is used for configuring MLServer advanced settings.

To configure the MLServer advanced information, perform the following steps:

Step	Action
1	Select the PLC ID from the left pane and click ADVANCED tab. The MLServer advanced information appears as shown in the following figure:



ATTENTION

Honeywell recommends that these settings and the default values (except for configured bases) need not be changed. If you need to change this configuration, contact the Honeywell technical support team.

4. Configuration

4.2. Configuring MLServer using Configuration Tool

Configure Bases is an option provided to configure the existing Bases to improve the performance of MLServer. This is an optional setting, For ML200R, bases 1 to 31 are available and for ML200IEC bases 1 to 7 are available.




Figure 4.2-1: Advanced tab for ML200IEC




Figure 4.2-2: Advanced tab for ML200R

For example, to configure bases 2 and 30, perform the following steps.

Step	Action
1	Select Base2 from the left list.
2	Click >> button.
3	B2 will be visible in the list on right side.
4	Click Save Configuration .

Note: If the configured bases are given, only the configured bases will be visible in Station. If not configured, few non-existing bases will also be visible in the Station.

Adding a new PLC

The PLCs in the plant must be added and configured in the MLServer Configuration tool for the MLServer to communicate with the PLCs.

To add a new PLC, perform the following steps:


Step	Action
1	Click Start > Programs > Honeywell MasterLogic Server > Configuration Tool .
2	Right click MLServer and select Add PLC .

4. Configuration

4.2. Configuring MLServer using Configuration Tool

Step

Action



A new PLC is added as shown in the following figure.

4. Configuration

4.2. Configuring MLServer using Configuration Tool

Step

Action

The screenshot shows the 'ML Server Configuration' window with the 'PLC' tab selected. The configuration is for PLC ML02. The 'General' section includes fields for PLC ID (ML02), PLC Name (MLPLC2), PLC Type (ML200R), and EPKS Asset Name (System). The 'Monitor' section has checkboxes for EPKS Write, IO Read, Auto Point Build, Status Read, and Alarm Raising, all of which are checked. The 'RTC' section has a checkbox for 'Enable Read/Write' which is checked, and input fields for 'Sync Interval' (5) and 'Deadband' (10). A 'Save Configuration' button is located at the bottom left of the window.

Section	Field	Value
General	PLC ID	ML02
	PLC Name	MLPLC2
	PLC Type	ML200R
	EPKS Asset Name	System
IP Addresses	IP Address1	0.0.0.0
	IP Address2	0.0.0.0
	IP Address3	0.0.0.0
	IP Address4	0.0.0.0
Monitor	EPKS Write	<input checked="" type="checkbox"/>
	IO Read	<input checked="" type="checkbox"/>
	Auto Point Build	<input checked="" type="checkbox"/>
	Status Read	<input checked="" type="checkbox"/>
	Alarm Raising	<input checked="" type="checkbox"/>
RTC	Enable Read/Write	<input checked="" type="checkbox"/>
	Sync Interval	5
	Deadband	10


4. Configuration

4.2. Configuring MLServer using Configuration Tool


Deleting a PLC

To delete a PLC, perform the following steps:

Step	Action
1	Click Start > Programs > Honeywell MasterLogic Server > Configuration Tool .
2	Right-click the PLC ID from the left pane and select Delete PLC .



The following confirmation message appears.




If you select **Yes**, the PLC configuration information is deleted.

Configuring MLServer general information

To configure the MLServer general information, perform the following steps:

Step	Action
1	Click Start > Programs > Honeywell MasterLogic Server > Configuration Tool .
2	Select MLServer from the left pane. <ul style="list-style-type: none"> The following window appears:



- Enter the **EPKS Asset Name** for the general MLServer Alarms. All Alarms raised by the MLServer is in this asset.
- Enter the **Log Retention Days** for the MLServer and Protocol Logs. The MLServer automatically deletes the log files that are older than these days.
- Enter the **PLC Info Update Rate** which indicates how fast the changes in the dynamic MLConfig XML parameters (Log files enabling / disabling, and so on) are detected.

4. Configuration

4.2. Configuring MLServer using Configuration Tool

Step	Action
6	Click  under MLServer Logs to browse and select the folder path to save the MLServer log files.
7	Select Request, Response, Trace and Monitor under MLServer Logs to generate the corresponding general logs.
8	Click  under Protocol Logs to browse and select the folder path to save the Protocol Stack log files.
9	Select Request, Response, Trace and Hex under Protocol Logs to generate the corresponding general logs.
10	Enter the scan period for General Diagnostic, PLC Diagnostic, IO Read, AD Module Read, Special Module Read and All Module Read under Scan Period . General Diagnostics – Frequency at which the general diagnostics parameters in the Driver Info Experion display are collected. PLC Diagnostics – Frequency at which the PLC specific diagnostics parameters in the Driver Info Experion display are collected. IO Read – Frequency at which the IO Module information is read from all the PLCs. AD Module Read – Frequency at which the AD Module information is read from the PLCs. Special Module Read – Frequency at which the Special Module parameters are read from the U memory area of the PLCs. The Bad PV is set for the corresponding Experion parameters based on this parameter. All Module Read – Frequency at which the module level errors, Max/Min/Current Scan periods are read from the F Area for the ML200 PLCs.
11	Click Save Configuration .  ATTENTION The configuration must be performed with MLConfig utility only in primary server. For all the configuration changes to be reflected in backup server, the replication of abstract folder and the Database synchronization must be performed between the primary and backup servers.

4.3 Configuring MLServer using Quick Builder

Overview of Quick Builder components

The MLServer must be configured using the Quick Builder. The configuration involves the following tasks:

- [Configuring the Quick Builder component manager](#)
- [Configuring a MasterLogic Channel](#)
- [Configuring a MasterLogic Controller](#)
- [Configuring an Experion Point \(Analog and Status\)](#)



REFERENCE - EXTERNAL

For more details on Experion Quick Builder tool, see Experion PKS Knowledge Builder > Experion PKS R400 > Configuration > Quick Builder Guide.



TIP

For example on configuring ML Channel, Controller and Points, refer to the sample QDB file (ML_Sample.qdb) in the installation folder.

Configuring the Quick Builder component manager

To enable configuring the MasterLogic Channel, MasterLogic Controller and Analog and Status Points in Quick Builder, the Quick Builder component manager must be configured.



ATTENTION

You must have Experion OPC client license (Model number: EP-OPCCLI) to configure the MasterLogic Channel, Controller and Point.


4. Configuration

4.3. Configuring MLServer using Quick Builder


To configure the Quick Builder component manager, perform the following steps:


Step	Action
------	--------

- 1 Create a new project in Quick Builder.
 - The **Enable Components** dialog box is displayed.
- 2 Select Experion server from **Server** drop-down list.
- 3 Click **Enable Components** tab.
- 4 Select **MasterLogic** from **Other** components.



- 5 Select **Analog Point** and **Status Point** from **Point** components.



Step	Action
6	Select Server from Server components.
	
7	Click OK .

Configuring a MasterLogic Channel

The MasterLogic Channel forms the interface between one or more MasterLogic Controllers and the MLServer.




ATTENTION

Configure only one MasterLogic Channel in an Experion server even if there are many PLCs that need to be connected through MLServer.

To configure the MasterLogic Channel, perform the following steps:

Step	Action
1	Create a new project in Quick Builder.
2	Right-click the Channel icon from the right-pane of the Quick Builder window and select Add Item .



The following dialog box appears.

4. Configuration

4.3. Configuring MLServer using Quick Builder

Step **Action**

Add Item(s)

Add Items: Channel

Number of items to Add: 1 Max:

Type: MasterLogic Channel

Name-CHAMAS

Use Name CHAMAS1

Format

Prefix CHAMAS

Variable

numeric

numeric with a 1 character field width

letter

Start 0 Step 1

Suffix

Summary

Add one item named 'CHAMAS'

OK Cancel

- 3 Select **Channel** and **MasterLogic Channel** type in the **Add Item(s)** dialog box.
 - 4 Select **Channels** icon from the left-pane of the Quick Builder window. From the right pane, select the channel that you want to configure.
 - 5 Configure the **Main** tab of the Channel as follows:
-

Step	Action
	<div style="border: 1px solid gray; padding: 5px;"> <p>Main</p> <p>Name <input type="text" value="CHAMAS1"/></p> <p>Description <input type="text"/></p> <p>Marginal Alarm Limit <input type="text" value="25"/></p> <p>Fail Alarm Limit <input type="text" value="50"/></p> <p>Connect Timeout <input type="text" value="10"/> secs</p> <p>Read Timeout <input type="text" value="2"/> secs</p> <p>Host Name (Preferred Data Source) <input type="text" value="localhost"/></p> <p>Host Name (Alternate Data Source) <input type="text"/></p> <p>Diagnostic Scan Period <input type="text" value="60"/> Background Scan Period <input type="text" value="60"/></p> <p>HCI Component <input type="text" value="Hci.MLPLCServer"/></p> <p>Item Type MasterLogic Channel</p> <p>Last Modified 4/24/2007 12:34:47 PM Item Number <input type="text" value="CHN01"/></p> <p>Last Downloaded</p> </div>

6 Ensure that the **Host Name** contains **localhost**.

7 Select the **Background Scan period**.

Note: This parameter is used in conjunction with the Controller's Background Scan parameter. Honeywell recommends you to retain the default value (60).



ATTENTION

Ensure that the **Item Number** for the channel configured is unique.

If the number of OPC channels configured in the Experion server is more than 5 or the number of OPC controllers configured is more than 20, then increase the channel "Connect Timeout" parameter to 15 seconds and "Read Timeout" parameter to 3 seconds. If the load is more than this limit, increase the connect timeout to 20 seconds.

4. Configuration

4.3. Configuring MLServer using Quick Builder

Step	Action
	WARNING <ul style="list-style-type: none">• The Background Scan Period,<ul style="list-style-type: none">– Must be greater than PV/OP/SP Scan Period. (The PV/OP/SP Scan Period is set during Point configuration).– Must not be equal to 0.• If the Background Scan Period is lesser than PV/OP/SP Scan Period, the MLServer does not function properly.
	REFERENCE – EXTERNAL <p>For more details on adding and configuring a Channel, see Experion Knowledge Builder > Experion PKS R400 > Configuration > Quick Builder Guide > Configuring Controllers and Channels.</p>

Configuring a MasterLogic Controller

The MasterLogic Controller is Quick Builder's mechanism for configuring one or more groups with the same deadband. It is a logic grouping and does not represent a physical device (that is the PLC controller).

To configure the MasterLogic Controller, perform the following steps:

Step	Action
1	Create a new project in Quick Builder.
2	Add a MasterLogic Channel to the project.
	REFERENCE – INTERNAL <p>For more details on adding a MasterLogic Channel, see Configuring a MasterLogic Channel.</p>
3	Right-click the Controller icon from the right-pane of the Quick Builder window and select Add Item . The Add Item(s) dialog box appears:
4	Select Controller and MasterLogic Controller in the Add Item(s) dialog box.
5	Select the Controllers icon from the left-pane of the Quick Builder window. From the right pane, select the controller that you want to configure.

Step	Action
------	--------

- | | |
|---|---|
| 6 | Configure the Main tab of the Controller as follows: |
|---|---|

The screenshot shows the configuration interface for a Master Logic Controller. The 'Main' tab is active. The configuration parameters are as follows:

- Name: CONMAS1
- Description: Master Logic Controller
- Channel Name: CHAMAS1
- Marginal Alarm Limit: 25
- Fail Alarm Limit: 50
- Background Scan: Enabled
- Deadband: 0.000

At the bottom of the form, the following information is displayed:

- Item Type: **MasterLogic Controller**
- Last Modified: **5/30/2007 3:40:02 PM**
- Item Number: **RTU001**
- Last Downloaded: (empty field)

- 7 Select the appropriate Channel from **Channel Name** list.

- 8 Select **Enabled** from **Background Scan** list.

Note: The PLC Points are scanned at Channel's **Background Scan period** interval if the Background scan period is enabled.

- 9 Select deadband value from **Deadband** drop-down list.

Note: This deadband applies to all items referenced by Point parameters belonging to this Controller. The unit of measurement is %.



REFERENCE - EXTERNAL

For more details on adding and configuring a Controller, see [Experion Knowledge Builder > Experion PKS R400 > Configuration > Quick Builder Guide > Configuring Controllers and Channels.](#)

4. Configuration

4.3. Configuring MLServer using Quick Builder

Configuring an Experion Point (Analog and Status)

Analog and Status Points are used for exchanging the MasterLogic data with Experion. The Quick Builder Point parameter represents a mapping to an item on the MLServer.



ATTENTION

The PV, SP and OP values are configured as parameters for a point. They do not refer to the general Process Control Industry meaning.

Configuring an Experion Analog Point

To configure the Experion Analog Point, perform the following steps:

Step	Action
1	Create a new project in Quick Builder.
2	Add a MasterLogic Channel and one (or more) MasterLogic Controller (s) corresponding to each PLC configured in the Plant.
	<hr/>
	 REFERENCE – INTERNAL For more details on adding MasterLogic Channel and Controller, see Configuring a MasterLogic Channel and Configuring a MasterLogic Controller .
3	Right-click the Point icon from the right-pane of the Quick Builder window and select Add Item . The Add Item(s) dialog box appears:
4	Select Point and Analog Point type in the Add Item(s) dialog box.
5	Select the Points icon from the left-pane of the Quick Builder window. From the right pane, select the point that you want to configure.
6	Configure the Main tab as follows:

Step	Action

- 7 Enter the **Parent Asset** for the point. All Alarms/Events raised by Experion (value change Events, Range checking Alarms, and so on.) is in this Asset.

**TIP**

Honeywell recommends that the Parent Asset configured for the points here must be the same as the **EPKS Asset Name** configured in the MLServer Configuration Tool for the PLC referred in this point.

- 8 Select ellipse  button next to **PV Source Address**.

The **Address Builder** dialog box is displayed.

- 9 Select **Controller** from **Address Type** drop-down list and appropriate Controller name from **Controller** drop-down list. Enter PLC Point name in **Location**.

Note: The PLC Point name includes the PLC ID, memory area, command, and data type. The name of the user-defined data format is also provided in the PLC Point name.

4. Configuration

4.3. Configuring MLServer using Quick Builder

Step	Action
------	--------



REFERENCE – INTERNAL

- For more details on PLC Point name, refer to [PLC Point configuration details](#).
- For more details on user-defined data format, see [Defining data formats](#).



WARNING

If the user defined data format is not defined in Experion, then the entire item is not recognized by the MLServer.

10 Configure the **Control** tab as follows:

The screenshot shows the MasterLogic configuration interface with the **Control** tab selected. The main window has tabs for Main, Display, Alarms, Control, Auxiliary, History, Scripts, and User Defined. The Control tab contains the following fields:

- Source Address: %MW21\$DEV
- Dest Address: %MW22\$DEV
- Scan Period (secs):
- Setpoint (SP): %MW21\$DEV
- Output (OP): %MW22\$DEV
- Mode (MD):
- Reverse Output
- Control Confirmat
- Low Control Limit**
- Output (OP) (%): 0
- Setpoint (SP) (EU): 0
- Control Deadband (%): 1.000
- Control Timeout: None
- Control Level: 0
- Normal Mode: AUTO
- Disable mode ch

An **Address Builder** dialog box is open over the Dest Address field. It has the following settings:

- Address Type: Controller
- Controller: CONMAS1
- Location: ML01.%MW21\$DEV

The dialog box includes OK, Cancel, and Help buttons.

Step	Action
11	<p>Enter setpoint's Source Address and Dest Address through Address Builder dialog box. (Optional)</p> <p>Note:</p> <ul style="list-style-type: none"> • Setpoint Source Address: This denotes the address from where SP reads the associated parameter value that can be viewed in the Experion Station. • Setpoint Dest Address: The value written to SP is transferred to this location in the PLC.
	<p> TIP</p> <p>Honeywell recommends you to configure the same PLC memory address for both the source and destination addresses of the SP parameter.</p>
12	<p>Select the Scan Period for SP.</p> <p>Note: This represents the interval at which the SP parameter's value is updated from the PLC Address specified in SP Source Address.</p>
	<p> WARNING</p> <p>The Scan Period,</p> <ul style="list-style-type: none"> – Must be less than the Background Scan Period configured for the MasterLogic Channel. – Must not be equal to 0.
13	<p>Enter Output's Source Address and Dest Address through Address Builder dialog box. (Optional)</p> <p>Note:</p> <ul style="list-style-type: none"> • Output Source Address: This denotes the address from where OP reads the associated parameter value that can be viewed in the Experion Station. • Output Dest Address: The value written to OP is transferred to this location in the PLC.
	<p> TIP</p> <p>Honeywell recommends you to configure the same PLC memory address for both the source and destination addresses of the OP parameter.</p>

4. Configuration

4.3. Configuring MServer using Quick Builder

Step	Action
14	Select the Scan Period for OP. Note: This represents the interval at which the OP parameter's value is updated from the PLC Address specified in OP Source Address.
	WARNING The Scan Period, <ul style="list-style-type: none">– Must be less than the Background Scan Period configured for the MasterLogic Channel.– Must not be equal to 0.
	TIP The values for SetPoint and Output need not be defined for every Experion point.
	REFERENCE – EXTERNAL For more details on adding and configuring Points, see Experion Knowledge Builder > Experion PKS R400 > Configuration > Quick Builder Guide > Point Properties.

Configuring an Experion Status Point





REFERENCE - INTERNAL

Configuring the **Main** tab of **Status Point** is similar to configuring the **Main** tab of an **Analog Point**. Instead of selecting an Analog Point, select a Status Point. For details about configuring an Analog Point, see [Configuring an Experion Analog Point](#).

To configure an Experion Status Point, perform the following:

Step	Action
1	Create a new project in Quick Builder.
2	Add a MasterLogic Channel and one (or more) MasterLogic Controller corresponding to each PLC configured in the Plant.


Step	Action
	<p data-bbox="618 495 948 522">REFERENCE – INTERNAL</p> <p data-bbox="618 548 1334 632">For more details on configuring a MasterLogic Channel and Controller, see Configuring a MasterLogic Channel and Configuring a MasterLogic Controller.</p>
3	<p data-bbox="526 653 1305 705">Right-click the Point icon from the right-pane of the Quick Builder window and select Add Item.</p>
	
	<ul style="list-style-type: none"> <li data-bbox="526 856 911 884">• The following dialog box appears:
	
4	<p data-bbox="526 1451 1227 1478">Select Point and Status Point type in the Add Item(s) dialog box.</p>
5	<p data-bbox="526 1499 1328 1554">Select the Points icon from the left-pane of the Quick Builder window. From the right pane, select the point that you want to configure.</p>
6	<p data-bbox="526 1575 889 1602">Configure the Main tab as follows:</p>

4. Configuration

4.3. Configuring MLServer using Quick Builder

Step	Action
------	--------

Step	Action
7	Enter the Parent Asset for the point. All Alarms/Events raised by Experion is in this Asset.
8	Select ellipse  button next to PV Source Address . <ul style="list-style-type: none">The Address Builder dialog box appears.
9	Select Controller from Address Type drop-down list and appropriate Controller name from Controller drop-down list. Enter PLC Point name in Location .



- 7 Enter the **Parent Asset** for the point. All Alarms/Events raised by Experion is in this Asset.



TIP

Honeywell recommends that the Parent Asset configured here must be the same as the **EPKS Asset Name** configured in the MLServer Configuration Tool for the PLC referred in this point.

- 8 Select ellipse  button next to **PV Source Address**.
- The **Address Builder** dialog box appears.
- 9 Select **Controller** from **Address Type** drop-down list and appropriate Controller name from **Controller** drop-down list. Enter PLC Point name in **Location**.


Note: The PLC Point name includes the PLC ID, memory area, command, and data type. The name of the user-defined data format is also provided in the PLC Point name.

Step	Action
------	--------

**REFERENCE - INTERNAL**

- For more details on PLC Point name, see [PLC Point configuration details](#).
- For more details on user-defined data format, see [Defining data formats](#).

10 Configure the **Control** tab as follows:



11 Enter **Output's Source Address** and **Dest Address** through **Address Builder** dialog box. (Optional)

Note:

- **Output Source Address:** This denotes the address from where OP reads the associated parameter value that can be viewed in the Experion Station.
- **Output Dest Address:** The value written to OP is transferred to this location in the PLC.

12 Select the **Scan Period** for OP.

Note: This represents the interval at which the OP parameter's value is updated from the PLC Address specified in OP Source Address.

4. Configuration

4.3. Configuring MLServer using Quick Builder

Step	Action
	WARNING The Scan Period, <ul style="list-style-type: none">– Must be less than the Background Scan Period configured for the MasterLogic Channel.– Must not be equal to 0.
	TIP The value for Output need not be defined for every Experion point.
	REFERENCE – EXTERNAL For more details on adding and configuring Points, see Experion Knowledge Builder > Experion PKS R400 > Configuration > Quick Builder Guide > Point Properties.

PLC Point configuration details



WARNING

Honeywell does not recommend modifying the QB database when MLServer is executing. After modifying QDB, restart MLServer by disabling and enabling the MLchannel.

The PLC Point name configured in Quick Builder provides a way of addressing the location in PLC where the values are stored. The PLC Point name specifies the PLC ID, memory address, the command to be executed, and the data type. For example, **ML01.%MW95\$CON**. The PLC Point name entered in the **Source Address** of Quick Builder for the Analog/Status Points is used for reading PLC data. The PLC Point name entered in the **Dest Address** is used for writing data into the PLC.

After downloading standard Points to Experion, enable the Channel, Controller and Points from the Experion Station. This triggers off connections to the MLServer based on the configured Channel, Controllers and Points. The MLServer then starts reading from or writing into PLCs using the commands embedded in the PLC Point name.

This section describes the various PLC Point name formats supported in ML200 IEC , ML200R and the commands used for reading or writing PLC information.

The following are the list of PLC Point name formats supported in ML200 R, ML200:

Table 4.3-1: PLC Point name formats supported in ML200R, ML200-IEC

PLC Point Name Format	ML200R	ML200-IEC
Direct Variable	✓	✓

The following table lists the different memory areas supported in ML200R and its associated data type, range and read/write property:

Table 4.3-2: Memory areas supported in ML200R

Memory Area	BIT	BYTE	WORD	DWORD	LWORD	INT	DINT	LINT	Range		Readable/ Writable
									Low	High	
I	✓	✓	✓	✓	✓	×	×	×	00.00.00	127.15.63	R
Q	✓	✓	✓	✓	✓	×	×	×	00.00.00	127.15.63	R/W
M	✓	✓	✓	✓	✓	×	×	×	00000	131071F	R/W
L	✓	✓	✓	✓	✓	✓	✓	✓	00000	11263F	R/W
F	✓	✓	✓	✓	✓	✓	✓	✓	00000	2047F	R
R	×	×	✓	✓	✓	✓	✓	✓	00000	32767	R/W
U	✓	×	✓	✓	✓	✓	✓	✓	00.00.00 0	31.15.511	R/W
W	×	×	✓	✓	✓	✓	✓	✓	00000	65535	R/W

Note: The R and W memory areas refer to the same storage locations for the first 32767 words. For example, %RW10 and %WW10 is referring to the same PLC memory address and therefore always have the same value.

4. Configuration

4.3. Configuring MLServer using Quick Builder

The following table lists the different memory areas supported in ML200-IEC and its associated data type, range and read/write property:

Table 4.3-3: Memory areas supported in ML200-IEC

Memory Area	BIT	BYTE	WORD	DWORD	LWORD	INT	DINT	LINT	Range		Readable/ Writable
									Low	High	
I	✓	✓	✓	✓	✓	✗	✗	✗	00.00.00	127.15.63	R
Q	✓	✓	✓	✓	✓	✗	✗	✗	00.00.00	127.15.63	R/W
M	✓	✓	✓	✓	✓	✗	✗	✗	00000	131071F	R/W
L	✓	✓	✓	✓	✓	✓	✓	✓	00000	11263F	R/W
F	✓	✓	✓	✓	✓	✓	✓	✓	00000	2047F	R
R	✗	✗	✓	✓	✓	✓	✓	✓	00000	32767	R/W
U	✓	✗	✓	✓	✓	✓	✓	✓	00.00.0	3F.31.F	R/W
W	✗	✗	✓	✓	✓	✓	✓	✓	00000	65535	R/W

Note: The R and W memory areas refer to the same storage locations for the first 32767 words. For example, %RW10 and %WW10 is referring to the same PLC memory address and therefore always have the same value.

The following table lists the various commands supported in ML200/ML200R:

Table 4.3-4: Commands supported in ML200R/ML200-IEC

Commands	Read	Write	Remarks
CON (ML200/ML200R)	<p>Continuous Read command</p> <p>If the PLC Point name ML01.%MW002\$CON and ML01.%MWIK004\$CON#REAL are passed for read, a single Continuous Read command is used for reading the 2nd and 4th Word of M memory area from PLC 01.</p>	<p>Continuous Write command</p> <p>If value is written to a Point's parameter that is configured as ML01.%MW002\$CON and ML01.%MW004\$CON#REAL a single Continuous Write command is used for writing the 2nd and 4th Word of M memory area in PLC 01.</p>	<p>Advantages:</p> <p>1) Useful when contiguous memory addresses need to be read from the PLC. Up to 1400 bytes can be read / written in a single packet. However, multiple CON packets can be created serving more number of points.</p> <p>2) This is the recommended method for ML200 when some continuous memory locations need to be read from PLC.</p> <p>Disadvantages:</p> <p>This command is not useful when a number of variables need to be read, where</p> <ul style="list-style-type: none"> the addresses are not contiguous or belong to different memory areas

4. Configuration

4.3. Configuring MLServer using Quick Builder

Commands	Read	Write	Remarks
DEV (ML200 IEC/ML200R)	<p>Device Area Read</p> <p>If the PLC Point name ML01.%MW95\$DEV is passed for read, the Device Area Read command is used for reading the 95th Word of M memory area from PLC 01.</p> <p>Device area read is also used to configure DISOE module points. For example, ML01.U1.0.0\$DEV#BIT@S OE. Here, device area read is used for reading 1st bit of U1.0.0 word.</p>	<p>Device Area Write</p> <p>If value is written to a Point's parameter that is configured as ML01.%MW95\$DEV, the Device Area Write command is used for writing the 95th Word of M memory area in PLC 01.</p>	<p>Advantages:</p> <p>This command is useful for reading/writing a few variables from/to different memory areas of the PLC. It reads/writes up to 80 variables in a single packet. However, multiple DEV packets can be created serving more number of points.</p> <p>Disadvantages:</p> <p>It is not useful for a larger number of variables. (For example: 500 variables.)</p>

Note:

- A single **Continuous Read/Write** command is used for reading or writing data together for multiple addresses within the same memory area.
- In ML200/ML200R, the maximum number of bytes read/written is 1400.
- The examples given in the previous table refer to ML200.



ATTENTION

- The default command in ML200/ML200R is **Device Area Read/Write**.
-



TIPS

Honeywell recommends to use the commands in the following order:

- a) **CON**: First try to use the CON (Continuous Read/Write) command. This is particularly useful when there are a lot of contiguous memory addresses that need to be read from / written to one or two PLC memory.
 - b) **DEV (Only for ML200/ML200R)**: This command must be used when data from different memory areas needs to be read and also for less number of points.
 - c) There is no limit on the number of points that can be configured.
-

Direct Variable

The following figure depicts the Direct Variable format:




Figure 4.3-1: Direct Variable

- **PLCID:** This refers to the PLC. It is a two digit number ranging from 01 through 99 and always prefixed by ML. This must be configured in MLServer Configuration Tool.
- **MemoryAddress:** This refers to the address within the PLC memory area where information is stored.

Format: %<MemoryArea><DataType><Offset>

- In ML200-IEC, for I and Q memory areas <Offset> are <Base>.<Slot>.<Position>. For other areas, it represents the address within the memory area.



REFERENCE – INTERNAL

For more details on memory areas supported in ML200R, see [Table 4.3-2](#).

For more details on memory areas supported in ML200-IEC, see [Table 4.3-3](#).

- **Command Type:** This refers to the different commands used for reading/writing data from/to PLC by MLServer. For more details on command types, see [Table 4.3-4](#).
- **Data Type:** This refers to the PLC data type.

**ATTENTION**

Only the following combinations of data types can be used in a Direct Variable.

Data type in Memory Address	Data type at the end of the PLC point name (after #)
X	BIT
B	BYTE
W	WORD and INT
D	DWORD, DINT and REAL
L	LWORD, LINT and LREAL

The request is sent to PLC with the data types configured in the memory address part (that is X, B, W, D and L) of the PLC point name. After receiving the responses, the MLServer converts it to the data type configured after #.

If no data type is configured in the PLC point name (that is no # part), by default the corresponding basic data type is used by the MLServer. For example, if the PLC point is configured as ML01.%MW90\$CON, then it would be assumed as ML01.%MW90\$CON#WORD.

The following table contains a list of examples for Direct Variable:

Table 4.3-5: Examples of Direct Variable

Direct Variable	
<p>Note: In the following examples, ML01 is a ML200-IEC PLC. The bit / word positions are 0-based.</p>	
Examples	<ul style="list-style-type: none"> • ML01.%MB105\$CON – This denotes the 1st Byte of the 53rd Word in the Internal memory area of PLC ML01. Continuous Read / Write is used for communication with PLC. • ML01.%IW2.3.1\$CON#INT – This denotes the 1st word in 3rd slot of Base2 in the Input memory area of PLC ML01. Continuous command is used for getting values from the PLC. The data is converted by MLServer and available as a signed integer value on the Experion side.

4. Configuration

4.3. Configuring MLServer using Quick Builder

Direct Variable

Note: In the following examples, ML01 is a ML200-IEC PLC. The bit / word positions are 0-based.

- **ML01.%RD80\$CON#REAL** – This denotes the 80th double word (that is 160th and 161st words) in R memory area of PLC ML01. The Continuous command is used for communication with the PLC. The data is converted by MLServer and available as a decimal (or REAL) value on the Experion side.

Defining data formats

Data formats are defined for converting PLC field values into engineering values. Experion provides default data formats for converting these field values. You also can define customized data formats.



REFERENCE - EXTERNAL

For more details on user-defined data formats, see [Experion Knowledge Builder > Experion PKS R400 > Configuration > Server and Client Configuration Guide > Understanding and configuring points > Advanced point configuration > Creating user-defined data formats.](#)

To create a customized data format, perform the following:



TIP

The following is a sample procedure explaining how to create a user-defined data format.


4. Configuration

4.3. Configuring MLServer using Quick Builder

Step

Action

- 1 Select **System Configuration** menu from the Experion Station.




- 2 Select **User-Defined Data Formats** in **Application Development**.

4. Configuration


4.3. Configuring MLServer using Quick Builder

Step

Action



3 Click an empty data format row.



Step	Action
4	Enter data format name in Name .
5	Select data type from Data Type drop-down list. For Example INT2.
6	Enter the minimum and maximum field values in Minimum and Maximum . For Example 0 and 16000 respectively.
7	Enter Field value and corresponding Converted value for Point 1 and Point 2 to define the conversion. For Example 0 and 1000 respectively. Example: If the field value is 8000, the corresponding converted value must be 500.
	ATTENTION While configuring the Points in Quick Builder,
If 100% Range value is...	Converted value ranges from...
1000	0 to 1000
100	0 to 100

The following table describes some sample field values and their corresponding engineering values in Experion:

Input Range	Data Format		Field value	PLC value	Engineering value (Converted value)
	PLC	Engineering			
0 to 5 volts	Minimum: 0 Maximum: 16000	Point 1: 0 Point 2: 1000	2.5 volts	8000	500
1 to 5 volts	Minimum: 0 Maximum: 16000	Point 1: 0 Point 2: 1000	2 volts	4000	250

4. Configuration

4.4. Downloading Quick Builder Points to Experion

4.4 Downloading Quick Builder Points to Experion

Overview

After adding and configuring items, you must download all or part of your project to the server database. The Channel, Controller or Point that have been imported or manually created in Quick Builder must be downloaded to Experion server database before you can use them.

The items are downloaded in the following sequence:

- MasterLogic Channel.
- MasterLogic Controller(s).
- Analog/Status Point(s).



REFERENCE – EXTERNAL

For more details on downloading items to Experion, see [Experion Knowledge Builder > Experion PKS R400 > Configuration > Quick Builder Guide > Managing items > Downloading items.](#)

After downloading, the MasterLogic Channel and MasterLogic Controller are enabled in the Experion Station using **View > System Status > Channels**.

4.5 Verifying the configuration

Overview

After downloading Points to the Experion, enable the Channel and Controller from the Experion Station.

After enabling the Channel and Controller, the following events occur:

- The MasterLogic server starts communicating with the PLCs using the configuration information from the Experion server database. A connection is established with the MLServer based on the Channel configuration.
- MLServer establishes communication with the PLCs using the IP Address & other PLC specific details configured using the configuration tool.
- The MLServer reads data from the PLC and transfers the values to the corresponding parameters in Experion Points. The data values written into these parameters are written into the appropriate memory locations in the PLC.
- Based on the status of the PLCs, the alarms/events are raised by the MLServer, in the Experion.
- The data, alarms raised by the PLCs and change of event in the PLCs can be monitored from the Experion Station.

You must ensure that PLCs are configured with correct IP address.

Verifying data exchange between PLC and Experion

The Point Detail display in the Experion Station helps in monitoring the online status of each parameter for a particular Point and the data exchange between the PLC and the Experion server.

- The parameter values set in the Point Detail display reflects in the Address monitoring window of the SoftMaster tool.
- The parameter values set in the Address monitoring window reflects in the Experion station.


4. Configuration

4.5. Verifying the configuration

The following procedure is an example to verify data exchange between the PLC and the Experion:

Step	Action
1	Configure the PLC information using the MLServer Configuration Tool.
2	Ensure that the ML16K user defined data format is configured in Experion.
3	Configure the MasterLogic Channel, MasterLogic Controller, Status and Analog Point in the Quick Builder and download to the Experion Server. Note: Consider a standard Analog Experion Point configured in Quick Builder as follows: <ul style="list-style-type: none">• PV source address as ML01.%MW10\$DEV ML16K• SP source and destination address as ML01.%MW80\$DEV ML16K The user-defined data format ML16K is used here to convert between the field value (0 to 16000) and the engineering value (0 to 1000).
4	Download the MasterLogic Channel, MasterLogic Controller and Point to the Experion Server.
5	Enable the Channel from the Channel Summary page in the Station . <ul style="list-style-type: none">• The MasterLogic Server starts communicating with the PLC using the configuration information.• The MasterLogic Server reads data from the PLC and transfers the values to the corresponding parameters in Experion Points. The data values written into these parameters are written into the appropriate memory locations in the PLC.

- | Step | Action |
|------|---|
| | <ul style="list-style-type: none"> Assume that the data value stored in the 10th word of M memory area is 8000. The following image shows the value displayed in the Address Monitoring window of the SoftMaster tool: |




4. Configuration

4.5. Verifying the configuration


Step

Action

The raw value (8000) is converted to the engineering value (500) because of the ML16K data format and updated in the PV parameter. This value is displayed in the **Station** as shown in the following image:



- | Step | Action |
|------|---|
| 6 | Change the value of M0010 memory location through the Change Current Value dialog box in Address Monitoring Window as shown in the following image: |



4. Configuration

4.5. Verifying the configuration

Step

Action

The raw value (12000) is converted to the engineering value (750) because of the ML16K data format and updated in the PV parameter. This value is displayed in the **Station** as shown in the following image:

The screenshot displays the 'Station - Default - Analog Point Detail (sysdtlana.htm)' window. On the left, a vertical scale shows a value of 750.00. The right side of the window is divided into several sections: 'Range' with input fields for Units, 100% (1000.00), and 0% (0.00); 'Services' with checkboxes for 'Scanning and Control enabled' and 'Alarms enabled'; 'Displays' with an 'Associated Display' field; and 'Algorithms' with 'PV Algorithm' and 'Action Algorithm' both set to 0. The status bar at the bottom indicates the date and time as 24-Aug-06 16:00:48, and the system status as Alarm System. A large 'X' watermark is visible on the right side of the screenshot.

Step	Action
7	Set a value 250 to SP parameter in the Station as shown in the following image:

4. Configuration

4.5. Verifying the configuration

Step

Action

The engineering value (250) is converted to the raw value (4000) and updated in the %MW80 memory location. This can be observed in the Address Monitoring window of the SoftMaster tool as shown in the following image:

	0	1	2	3
%MW0	0000	0000	0000	0000
%MW4	0000	0000	0000	0000
%MW8	0000	0000	8000	0000
%MW12	0000	0000	0000	0000
%MW16	0000	0000	0000	0000
%MW20	0000	0000	0000	0000
%MW24	0000	0000	0000	0000
%MW28	0000	0000	0000	0000
%MW32	0000	0000	0000	0000
%MW36	0000	0000	0000	0000
%MW40	0000	0000	0000	0000
%MW44	0000	0000	0000	0000
%MW48	0000	0000	0000	0000
%MW52	0000	0000	0000	0000
%MW56	0000	0000	0000	0000
%MW60	0000	0000	0000	0000
%MW64	0000	0000	0000	0000
%MW68	0000	0000	0000	0000
%MW72	0000	0000	0000	0000
%MW76	0000	0000	0000	0000
%MW80	4000	0000	0000	0000
%MW84	0000	0000	0000	0000
%MW88	0000	0000	0000	0000
%MW92	0000	0000	0000	0000

5. Monitoring PLC status from Experion displays

5.1 Overview

Experion displays

The Experion standard Station displays and the Custom displays are used for monitoring the PLC status.

The following are the Experion standard Station displays:

- Channel Summary page
- Point Detail display

The following is the Experion Custom display:

- PLC System Status display



ATTENTION

To view the PLC information in the graphics pages, ensure that the points corresponding to the PLCs are configured using the Point Build utility.

5.2 Building a Point in Experion corresponding to the PLC

Using Configuration tool

The information required by the Experion Graphics is stored in the user-defined parameters of Experion points configured for each PLC. These PLC level Points are built by enabling the Auto Point Build option in ML Server Configuration Tool. If these points are not built, then the data communication between the MLServer and Experion does not appear in the Experion custom displays.


To build Points for the configured PLCs, perform the following steps:

Step	Action
1	Configure the PLC information using the MLServer Configuration Tool, for each PLC with which the MLServer must communicate. Ensure that EPKS Asset Name is configured in the tool.
	 REFERENCE – INTERNAL For more information about configuring the PLC information, see Configuring PLC Information.

5. Monitoring PLC status from Experion displays

5.2. Building a Point in Experion corresponding to the PLC

Step	Action
2	Select the Auto Point Build option.




- 3 Click **Save Configuration**.
- 4 The output files with extension **.out** and **.pnt** are created.

For example:

- The **MLPLC_StatusPoints.pnt** file is created. This file contains the information about the points to be built in Experion corresponding to the selected PLCs.
- The **MLPLC_StatusPoints.out** file shows the status of Point building.

5. Monitoring PLC status from Experion displays

5.2. Building a Point in Experion corresponding to the PLC

Step	Action
5	<p data-bbox="477 495 542 558"></p> <p data-bbox="618 495 773 520">ATTENTION</p> <p data-bbox="618 548 1273 604">If there is an error during point building the following message appears:</p> <div data-bbox="618 625 1227 877"></div> <p data-bbox="477 898 1133 926">Restart MLServer for any configuration changes to take effect.</p>
	<p data-bbox="477 982 631 1008">ATTENTION</p> <p data-bbox="477 1035 1170 1062">Restart the MLServer for the configuration changes to take effect.</p>

5.3 Using Experion custom displays

PLC System Status Display

The PLC information is displayed in the Experion Station using custom displays.

The following are the three tabs available in the custom displays used for viewing the PLC information:

Tab name	File name	Description
Config Info	MLPLC_Config.htm	This page displays the basic PLC information and diagrammatic representation of the modules with base/slot information.
Status Info	MLPLC_Status.htm	This page displays the PLC status diagnostics information.
Driver Info	MLPLC_Driver.htm	This page displays the MLServer interface driver diagnostics information.

Config Info

The **Config Info** page is used for monitoring the base slot information of each PLC and the status of communication between the PLC and the Experion server.

The following PLC information appears in the **Config Info** page:


- PLC Name
- PLC ID
- PLC Type
- Base number
- Last RTC time
- Diagrammatic representation of the modules with base/slot information

5. Monitoring PLC status from Experion displays


5.3. Using Experion custom displays

To view the general PLC and base/slot information in the Experion display, perform the following steps:

- | Step | Action |
|------|---|
| 1 | Ensure the Auto Point Build check box in Config tool is enabled. |



- 2 Click **Start > Programs > Honeywell MasterLogic Server > Configuration Tool** and select the PLC.
- 3 Select **EPKS Write** and **IO Read** check boxes under **Monitor** using the **MLServer Configuration Tool**.



- 4 Invoke the Experion Station.
 - 5 Enter `MLPLC_config.htm` in the **Command** zone. Press **Enter**.
-

5. Monitoring PLC status from Experion displays

5.3. Using Experion custom displays

Step

Action

- The following page appears for ML 200R:

Module#	Module Description
51602MLL-EPMT	Fast Ethernet Module, Optical Master
51612MLL-EPMT	Fast Ethernet Module, Optical Master
5162 Empty	
5163 Empty	
5164 Empty	
5165 Empty	

18-May-09 23:38:37 DBGSRVR MLPLC1 DISCONNECTED U 01 Disconnected from IP 10.14.11 DISCONNECTED							
Honeywell	19-May-08	11:04:27		System	vistaserver	Str01	Mngr

- Select the name of a PLC from the **PLC** dropdown list.
 - The PLC ID, PLC Type, Base, IP Addresses and Last RTC Read Time are displayed.

Note: All the fields in the page (except the **PLC Name** and **Base Number**) are not editable. The **IP Address** indicated in green is the active IP Address.

- Select base number from the **Base** dropdown list.

Note: Base 0 is selected by default.

The following information is displayed diagrammatically:

- CPU status
- Different slots of the selected base.

5. Monitoring PLC status from Experion displays


5.3. Using Experion custom displays

Step	Action
	The following information appears in 3 columns in the lower part of the window: <ul style="list-style-type: none">• The Name column indicates the slot position and module name.• The Assigns Information column indicates the module information.• The Description column indicates the module description.

Viewing RTC time in Config Info page

The PLC time must be synchronized with the Experion system time. The MLServer reads the PLC time and compares with the Experion system time, based on the settings in MLServer Configuration Tool. If there is a time difference, the PLC time is updated with the Experion system time. The RTC time read from the PLC is displayed in the Config Info graphics page.

The following figure depicts how the PLC time is synchronized with the Experion system time:



To view the RTC time in the **Config Info** page, perform the following steps:

Step	Action
1	Click Start > Programs > Honeywell MasterLogic Server > Configuration Tool and select the PLC.

5. Monitoring PLC status from Experion displays

5.3. Using Experion custom displays

Step	Action
2	Select EPKS Write under Monitor and Enable Read/Write under RTC using the MLServer Configuration tool.

The screenshot shows two panels: 'Monitor' and 'RTC'. The 'Monitor' panel has three checked checkboxes: 'EPKS Write', 'IO Read', and 'Auto Point Build'. The 'RTC' panel has one checked checkbox: 'Enable Read/Write'. Below this checkbox are two input fields: 'Sync Interval' with the value '5' and 'Deadband' with the value '10'.

- 3 Enter **SynchInterval** under **RTC**.

Note: This indicates the time frequency for reading the RTC time from the PLC. If this value is 0 then the RTC time is not read or written from/to the PLC.

- 4 Enter **Deadband** under **RTC**.

Note: The PLC time is updated with the Experion system time, if the time difference is equal to or greater **Deadband** (in seconds). If this value is 0 then the RTC time is not written to the PLC.

- The RTC time is displayed in the **Config Info** page as shown in the following figure:

The screenshot shows a status bar with the following information: PLC : MLPLC1, PLC ID : ML01, PLC Type : ML200, Base : Base 0, Last RTC Read Time : 09-Feb-2007 16:53:47.

Status Info

The **Status Info** page is used for monitoring the online status of each PLC, the MLServer and the data exchange between the PLC and the Experion server.


- The parameter value for the PLC status set in the xml files is used for updating the PLC status information in the Experion graphics pages.

5. Monitoring PLC status from Experion displays


5.3. Using Experion custom displays

To verify the PLC status information updates in the Experion graphics pages, perform the following steps:

- | Step | Action |
|------|---|
| 1 | Ensure the Auto Point Build check box in Config tool is enabled. |



- Click **Start > Programs > Honeywell MasterLogic Server > Configuration Tool** and select the PLC.
- Select **EPKS Write** and **Status Read** check boxes under **Monitor** using the **MLServer Configuration** tool.




- The status of the CPU operation mode is updated in the Experion graphics display.

5. Monitoring PLC status from Experion displays

5.3. Using Experion custom displays

- | Step | Action |
|------|--|
| 4 | Open MLPLC_Config.htm from the Experion Station and select the PLC for which you want to view the status. See Config Info for more details. |
| 5 | Click Status Info tab. <ul style="list-style-type: none"> The following page appears for ML 200R: |



CPU Operation Mode

RUN	CPU operation is in run mode.
STOP	CPU operation is in stop mode.
ERROR	CPU operation is in error mode.
DEBUG	CPU operation is in debug mode.

Last Mode Change By

KEY	Operation mode change by key.
Local PADT	Operation mode change by local SoftMaster.

5. Monitoring PLC status from Experion displays

5.3. Using Experion custom displays

Step	Action
Remote PADT	Operation mode change by remote SoftMaster.
Remote Comn.	Operation mode change by remote communication module.
Local / Remote	
Local	Operation mode change only by mode key.
Remote	Remote mode operation.
Online Editing	
Download	Revised program stand-by when revising on the run.
Internal Proc	Revising on the run during internal processing.
Done	Revising on the run is completed as normal.
Error	Revising on the run is completed as normal.
Miscellaneous Flags	
Forced Input	Force on/off by input points.
Forced Output	Force on/off by output points.
Skip I/O	Designated Input/output module for stopping trouble check and data refresh.
Fault Mask	Designated Input/output module for proceeding operation even in time of trouble.
Monitor Mode	External monitor running for program and variables.
CPU MODBUS Port	CPU Mode bus slave service is active.
Stop Instruction	Stop after scan completion by STOP function during RUN mode operation.
ESTOP Instruction	Immediate stop by ESTOP function during RUN mode operation.
Scan Time (Milli Seconds)	
Maximum	Maximum PLC CPU scan period.
Minimum	Minimum PLC CPU scan period.

5. Monitoring PLC status from Experion displays
5.3. Using Experion custom displays

Step	Action
Current	Current PLC CPU scan period.
CPU Error Status	
Configuration Error	Normal operation is impossible because of the CPU module self-diagnosis error.
Module Detach Error	When actual module and each slot I/O configuration parameter are not matched.
Digital I/O Module Error	When each slot module's input/output module cannot normally read and write this error is displayed.
External Equipment	External equipments serious trouble written in ANC_ERR[n] is shown by user program.
Module Type Mismatch	When actual module and each slot I/O configuration parameter are not matched.
Module Fuse Blown	When each slot module with fuse is short, this error is displayed.
Special / Comn. Module	When interface does not work because of special or communication module's malfunction its error is displayed.
SCAN Watchdog Error	When scan watchdog time is exceeded because of its parameter.
Basic Parameter Error	Basic parameter error is checked and displayed.
I/O Parameter Error	When each slot module's input/output module cannot normally read and write this error is displayed.
Comn. Module Parameter Error	Communication module parameter error is checked and displayed.
Program Code Error	User program error is checked and displayed.
Base Power Error	Base power error.
CPU Warnings	
RTC Error	RTC data error.

5. Monitoring PLC status from Experion displays

5.3. Using Experion custom displays

Step	Action
Task Collision	An identical task is double-requested during user program running; the collision with the previous task is displayed.
Fixed Cycle Scan Error	If scan time is longer than the designated 'fixed cycle', it becomes 'ON'.
External Equipment	When external equipments' warning written in ANC_WB[n] by user program, its trouble is displayed.
Data Backup Error	Data memory is destroyed because of back-up error and thus, restart program (hot or warm) revision is impossible. Regarding cold restart running, this flag is possible to use for initializing program and is automatically reset once initializing program is completed.
Battery Failure	When battery voltage for user program and data memory back-up is below the standard.
Log Memory Full	When PLC's log memory becomes full.
Communication Status Flags	
HSL1	They are representative flags when high speed link is impossible after checking each high speed link error on high speed link Enabling situation. If high speed link is disabled, it is reset.
P2P1	They are representative flags when P2P running is impossible after checking each P2P parameter error on P2P Enabling situation. If P2P is disabled, it is reset.
<ul style="list-style-type: none"> The CPU Type and OS Version (CPU firmware version) are displayed. 	
The PLC Status information is displayed in 5 different tabs.	
SYS State tab	Displays the PLC system operation status.
Slot Info	Displays the information for different slots.
PADT_CNF	Displays the PADT configuration information.
CNF_ER	Displays error messages and status of stopping the operation.

5. Monitoring PLC status from Experion displays

5.3. Using Experion custom displays

Step	Action
CNF_WAR	Displays the warning flags with respect to quick operations.
DOMAIN_ST	Displays the information on System software configuration.



ATTENTION


The option of selecting another PLC is not available in **Status Info** page. To view another PLC's status, select a PLC name from **Config Info** page and click **Status Info** tab.

- The CPU operation in run mode is displayed in the Experion graphics display as shown in the following figure:

The screenshot displays the 'Status Info' page for PLC MLPLC1. The CPU is in RUN mode. The status bar at the bottom shows 'System' in green, indicating the PLC is operational. The page includes sections for CPU Type (2MLR:CPUWT), OS Version (1.5), Scan Time (Minimum: 146.50, Maximum: 100.40, Current: 122.40), CPU Error Status, CPU Warnings, and various flags (Miscellaneous, Communication, etc.).

- Click **Stop** button in the SoftMaster tool or using the keys on the PLC, change the CPU operation mode to stop.

5. Monitoring PLC status from Experion displays
5.3. Using Experion custom displays

Step	Action
	 <p>The screenshot shows the SoftMaster software interface. The title bar reads "SoftMaster - [NewProgram[Program]]". The menu bar includes Project, Edit, Find/Replace, View, Online, Monitor, Debug, Tools, Window, and Help. The toolbar contains various icons, with the Run button (a play symbol) circled in blue. Below the toolbar is a keyboard shortcut row with keys like F3, F4, sF1, sF2, F5, F6, sF8, sF9, F9, F11, sF3, sF4, sF5, sF6, F10, sF7. The main workspace is divided into several panes: a Project Window on the left showing a tree view with "new", "NewPLC(2MLI-CPUU)-Run/Er...", "Global Variables/Address", "Parameter", and "Basic Parameters"; a Function/FB pane below it with a "Most Recently Used" list and an "Edit" button; a Variable Monitoring Window at the bottom left with a table and navigation buttons; and a Message Window at the bottom right displaying status information. The Message Window text includes: "Global Variable is being checked...", "No error occurred.", "Execution codes: 408Bytes are used.", "Upload programs: 449Bytes are used.", and "Auto variables: 0Bytes are used. (0%)". The bottom status bar shows "NewPLC" and "Run" buttons.</p>

5. Monitoring PLC status from Experion displays
 5.3. Using Experion custom displays

Step	Action
------	--------

- The following message appears:



7 Click **Yes**.

- The CPU operation mode status is updated in the graphics display within few seconds as shown in the following figure:

Module#	Address Information	Module Description
Slot0: Empty	[00000 - 0000F]	
Slot1: Empty	[00040 - 0007F]	
Slot2: ZMLC_EPM1	[00080 - 0011F]	Fast Ethernet Module, Optical Master
Slot3: Empty	[00120 - 0015F]	
Slot4: Empty	[00160 - 0019F]	
Slot5: Empty	[00200 - 0023F]	

27-Jun-08 11:31:31 SERVER_102 MLPLC1_MSTR_SYS_STATE_STOP ALARM U 01 12015 - MASTER CPU Stopped 1
 Honeywell 27-Jun-08 11:31:39 System vistaserver Str01 Mngr

8 Click  in the SoftMaster tool or using the keys on the PLC, change the CPU operation mode to run.

- The following message appears:

5. Monitoring PLC status from Experion displays


5.3. Using Experion custom displays

Step	Action
------	--------



9 Click **Yes**.

- The CPU operation mode status is updated in the graphics display within few seconds as shown in the following figure:




Driver Info


The MLServer diagnostic parameter information appears in the **Driver Info** page. This page is used for viewing the status of communication between the MLServer, PLC and the Experion.

To view the MLServer diagnostics information, perform the following steps:

Step	Action
1	Click Start > Programs > Honeywell MasterLogic Server > Configuration Tool and select the PLC.
2	Select EPKS Write check box under Monitor using the MLServer Configuration tool.



- 3 Select **MLServer** from the left pane. Enter the frequency for **General Diagnostic** and **PLC Diagnostic** under **ScanPeriod** of the **MLServer** tab.



The image shows a "Scan Period" configuration window with six input fields. The values entered are: General Diagnostic (60), PLC Diagnostic (30), IO Read (3600), AD Module Read (10), Special Module Read (10), and All Module Read (10).

- 4 Open **MLPLC_Config.htm** from the Experion Station and select the PLC for which you want to view the Driver Diagnostics information. See [Config Info](#) for detailed procedure.
- 5 Select **Driver info** tab.
-

5. Monitoring PLC status from Experion displays

5.3. Using Experion custom displays

Step	Action
------	--------

- The following page appears:

PLC General Parameters	PLC Specific Parameters	Protocol Stack Parameters
MLServer Parameters	PLC Connection Status	Large Buffers Available
MLConnk :ML Status	Success	Small Buffers Available
MLMonitor :ML Status	Success	Medium Buffers Available
MLAppSettings :ML Status	Success	Request Queue Size
MLServer Start Time	19-May-2009 10:54:01	PS Request Thread Status
PSCommunication Status	Connected	PS Response Thread
Main Response Thread Status	Running	PS TB COS Thread Status
HCI Callback Thread Status	Running	Last Response Received Time
EPKS Commn Thread	Running	Last Request Sent Time
Main Response Queue Size	Running	Last TBResponse Received Time
Current Static RequestID	8000	Last COSResponse Received Time
Current Dynamic RequestID	15002	Max Response Time (ms)
Number Of Requests	2	Min Response Time (ms)
Number Of Responses	3	Avg Response Time (ms)
Diagnostics UDP Updated Time	19-May-2009 10:54:02	Last PLC Connected Time
Protocol Stack Parameters		Last PLC Disconnected Time
Engine Thread Status	Running	Last HB Sent Time
License Parameters		Last Status Received Time
Licensed Number Of PLCs	Unlimited	
Licensed Number Of Points	5000	
Licensed Mode	Permanent	



ATTENTION

The option of selecting another PLC is not available in **Driver Info** page. To view another PLC's driver diagnostics, select a PLC name from **Config Info** page and click **Driver Info** tab.

The following table lists the MLServer diagnostics parameters displayed in the graphics page:

Parameter Name	Description
PLC General Parameters – MLServer Parameters	
ML Config XML Status	Indicates the status of MLConfig XML read.
ML Monitor XML Status	Indicates the status of MLMonitor XML read.
ML AppSettings XML Status	Indicates the status of MAppSettings XML read.
MLServer Start Time	Indicates the latest start time of the MLServer.
PSCommunication Status	Indicates the status of the communication between the MLServer and Protocol Stack.
Main Response Thread Status	Indicates the status of MLServer main response thread.
HCI Callback Thread Status	Indicates the HCI call back thread Status
EPKS Commn Thread Status	Indicates the Experion communication thread Status
Main Response Queue Size	Indicates MLServer main queue size.
Current Static Request ID	Indicates the static Request ID assigned to the command sent to PLC.
Current Dynamic Request ID	Indicates the dynamic Request ID assigned to the command sent to PLC.
Number of Requests	Indicates number of requests sent to Protocol stack in one second.
Number of Responses	Indicates the number of responses received from Protocol stack in one second.
Diagnostics UDP Updated Time	Indicates the time when the Diagnostics related Experion UDP parameters were last written by MLServer.
PLC General Parameters – Protocol Stack Parameters	
Engine Thread Status	Indicates the status of ML protocol engine thread.

5. Monitoring PLC status from Experion displays

5.3. Using Experion custom displays

Parameter Name	Description
PLC Specific Parameters – MLServer Parameters	
PLC Connection Status	Indicates the status of the connection between the PLC and MLServer.
Request Thread Status	Indicates the status of the thread sending requests to the Protocol stack.
Response Thread Status	Indicates the status of the thread processing responses from the Protocol stack.
Monitor Thread Status	Indicates the status of the thread sending requests on Status, Base slot, AD Module to the Protocol stack.
Response Queue Size	Indicates the size of the response queue holding the responses from the Protocol stack.
EPKS Write Queue Size	Indicates the queue holding the UDP values to be written to the Experion.
EPKS Alarm Queue Size	Indicates the queue holding the alarms to be raised in Experion.
Current Static Request ID	Indicates the static Request ID assigned to the command sent to the PLC.
Current Dynamic Request ID	Indicates the dynamic Request ID assigned to the command sent to the PLC.
Number of Requests Per Sec	Indicates the number of requests sent to Protocol stack in a second.
Number of Response Per Sec	Indicates the number of responses received from the Protocol stack in a second.
Number of EPKS Writes Per Sec	Indicates the number of Experion UDP writes in a second.
Number of EPKS Alarms/Events Per Sec	Indicates the number of Experion alarms raised in a second.
Status UDP Updated Time	Indicates the time when the Status related Experion UDP parameters were last written by MLServer

5. Monitoring PLC status from Experion displays

5.3. Using Experion custom displays

Parameter Name	Description
Base Slot UDP Updated Time	Indicates the time when the Base slot related Experion UDP parameters were last written by MLServer
AD Module UDP Updated Time	Indicates the time when the AD Module related Experion UDP parameters were last written by MLServer
Special Module UDP Updated Time	Indicates the time when the Special Module related Experion UDP parameters were last written by MLServer
Miscellaneous UDP Updated Time	Indicates the time when the Miscellaneous Experion UDP parameters were last written by MLServer
Diagnostics UDP Updated Time	Indicates the time when the Diagnostics related Experion UDP parameters were last written by MLServer
RTC Read UDP Updated Time	Indicates the time when the RTC read related Experion UDP parameters were last written by MLServer
RTC Write Updated Time	Indicates the time when the RTC write related Experion UDP parameters were last written by MLServer
PLC Specific Parameters – Protocol Stack Parameters	
Large Buffers Available	Indicates the number of large buffers maintained by Protocol stack.
Small Buffers Available	Indicates the number of small buffers maintained by Protocol stack.
Medium Buffers Available	Indicates the number of medium buffers maintained by Protocol stack.
Request Queue Size	Indicates the size of the request queue maintained by Protocol stack.
PS Request Thread Status	Indicates the status of thread that processes requests in Protocol stack.
PS Response Thread Status	Indicates the status of thread that processes responses in Protocol stack.

5. Monitoring PLC status from Experion displays

5.3. Using Experion custom displays


Parameter Name	Description
PS TB COS Thread Status	Indicates the status of thread that processes TB COS responses in Protocol stack.
Last Response Received Time	Indicates the time of receiving last response from the PLC socket.
Last Request Sent Time	Indicates the time of sending last request to the PLC socket.
Last TB Response Received Time	Indicates the time of receiving last TB response from the PLC socket.
Last COS Response Received Time	Indicates the time of receiving last COS response from the PLC socket.
Max Response Time (ms)	Indicates the maximum time taken to receive response from PLC.
Min Response Time (ms)	Indicates the minimum time taken to receive response from PLC.
Avg. Response Time (ms)	Indicates the average time taken to receive response from PLC.
Last PLC Connected Time	Indicates the last time when protocol stack was connected to PLC socket.
Last PLC Disconnected Time	Indicates the last time when protocol stack was disconnected from PLC socket.
Last HB Sent Time	Indicates the last time when Heart Beat message was sent to PLC.
Last Status Received Time	Indicates the last time when status response was received from PLC.

5.4 Using Experion standard Station displays

Channel Summary page

To enable the ML Channel through Channel Summary page, perform the following steps:

Step	Action
1	Invoke the Experion Station.
2	Select View > System Status > Channels . <ul style="list-style-type: none">The Channel Summary page appears.



- 3 Select the check box corresponding to the Channel to enable it.



ATTENTION

The Channel status OK corresponds to the communication status between MLServer and Experion server (OPC Communication). It does not correspond to the communication with PLC. If communication is lost with PLC, the alarm for corresponding IP will be raised and all the point status will set in inverted state.


5. Monitoring PLC status from Experion displays

5.4. Using Experion standard Station displays

Point Detail display

To view Point Detail display, perform the following steps:

- | Step | Action |
|------|---|
| 1 | Invoke the Experion Station. |
| 2 | In the Station Command Zone, enter the name of the Point. Press F12 . <ul style="list-style-type: none">The Point Detail page appears. |



REFERENCE - EXTERNAL

For more information on Experion displays, see [Experion Knowledge Builder](#).

5.5 Monitoring PLC displays from an Experion client system

Overview

The PLC status can be viewed from an Experion client system using the PLC displays. To view the PLC status from an Experion client system, perform the following steps:

Step	Action
1	The graphics pages and the xml files must be available in the client system for viewing the PLC information in the client system. If the files are not available, ensure to copy the graphics pages and xml files from the installation path (typically C:\Program Data\Honeywell\Experion PKS\Client\Abstract) to the client system in the same path.
2	The connection properties of the Experion Station must have the folder path C:\Program Data\Honeywell\Experion PKS\Client\Abstract in the list. This allows the viewing of PLC information in the client system.

5.6 Bad quality items

Overview

Experion Point parameters are configured in Quick Builder with PLC Points for data exchange between PLC and Experion. The quality of the Experion Point parameter indicates the status of the data in PLC or the data communication with Experion.

MasterLogic-Experion integration enables the monitoring of analog input signal failures such as transmitter failure or disconnection of input signal. All channels of all analog input modules are constantly monitored for input signal failure. If the input signal fails, all Experion points configured for this input channel is set to BADPV status for safer control of the plant.

The BADPV setting is applicable for the following modules:

Module Type	Model#	Description
Analog Input module	2MLF-AV8A	<ul style="list-style-type: none">Voltage Input: 8 channelDC 1 ~ 5V / 0 ~ 5V / 0 ~ 10V / -10 ~ +10V
	2MLF-AC8A	<ul style="list-style-type: none">Current Input: 8 ChannelDC 4 ~ 20mA / 0 ~ 20mA
	2MLF-AD8A-	<ul style="list-style-type: none">Voltage/Current Input 8 ChannelDC 1 ~ 5V / 0 ~ 5V / 0 ~ 10V / -10 ~ + 10V 4~20mA/0~20mA
	2MLF-AD16A	<ul style="list-style-type: none">Voltage/Current Input: 16 channelDC 1 ~ 5V / 0 ~ 5V / 0 ~ 10V / -10 ~ + 10V 4 ~ 20mA / 0 ~ 20mA

The following explains the two ways of setting quality for the Point parameter:


- Setting quality for Channel disconnection in the field.
- Setting quality for the item based on the PLC Read command responses.

5. Monitoring PLC status from Experion displays
5.6. Bad quality items

Viewing bad quality item in Point Detail display

To view the bad quality for Analog Input modules data in the Point Detail display, perform the following steps:

- | Step | Action |
|------|---|
| 1 | Click Start > Programs > Honeywell MasterLogic Server > Configuration Tool and select the PLC. |
| 2 | Select EPKS Write and IO Read check boxes under Monitor in the configuration tool to view the IO module information in the Experion graphics display. To view PLC status information in Experion graphics display, select Status Read and Alarm Raising check boxes. |




- 3 Consider an IO Module in Base 0 Slot 2 that is also an AD Module and Special Module.
- 4 Configure the Input Range as 1~5V in the SoftMaster tool. Ensure to write the IO Module configuration to the PLC.

Parameter	CH 0	CH 1	CH 2	CH 3	CH 4	CH 5	CH 6	CH 7
<input type="checkbox"/> Channel status	Enable							
<input type="checkbox"/> Input range	1~5V							
<input type="checkbox"/> Output type	0~16000	0~16000	0~16000	0~16000	0~16000	0~16000	0~16000	0~16000
<input type="checkbox"/> Filter process	Disable							
Filter constant	1	1	1	1	1	1	1	1
<input type="checkbox"/> Average setting	Disable							
<input type="checkbox"/> Average processing	Count-Avr							
Average value	2	2	2	2	2	2	2	2

5. Monitoring PLC status from Experion displays

5.6. Bad quality items

- | Step | Action |
|------|---|
| 5 | Configure a PLC Point as ML01.U01.02.06 in Quick Builder and download to the Experion server. |



Note: The PLC point must be configured with U01.02.06, where 01 is Base No1, 02 is Slot no 2, and 06 for Channel no 4. This can be identified from the Global variable in SoftMaster.


- | | |
|---|--|
| 6 | Enable the Channel containing the configured PLC Point. |
| 7 | Connect the input signal to Channel 4 (first Channel is 0) of the IO Module. |

5. Monitoring PLC status from Experion displays
5.6. Bad quality items

Step

Action

- View the status of the data communication in the Station display.



5. Monitoring PLC status from Experion displays

5.6. Bad quality items

Step	Action
------	--------


- | | |
|---|---|
| 8 | Disconnect the input signal from Channel 4. <ul style="list-style-type: none"> View the status of the data communication in the Station display. |
|---|---|

Note: The previous example is for Channel 4. If you want to test with a different channel in the IO module, ensure that the data item configured in Experion is also changed appropriately.

5. Monitoring PLC status from Experion displays
5.6. Bad quality items

Step **Action**

- Alarm is raised corresponding to the disconnected channel with Base number and Slot number as shown in the following figure.



21-Apr-07 10:37:29 SERVER_101 BOS2_ChannelConnection_0 ALARM U 00 Base 0, Slot 2 Channel 0 Connected 1
Honeywell 21-Apr-07 10:38:34 Alarm System Message ie10dt8kkdgd1s Str01 Mngr

6. Alarms and Events integration

6.1 Alarm integration

Types of Alarms

The following are the two types of Alarms raised by the MLServer:

- **PLC Status diagnostics Alarms** – These alarms are raised based on the current PLC Status.
- **Error indicating Alarms / Messages** – Important errors that require immediate attention are also raised as System Alarms. The other errors are raised as Messages.

The Asset configured in the PLC tab of the configuration tool, for that particular PLC, is used while generating the Alarms/Events.

PLC Status Diagnostics alarms

After downloading Points to the Experion server, the MLServer starts receiving the status data from the PLC at every configured interval (default is 10 seconds).

Alarms are raised based on the present PLC status. Another PLC level alarm is raised corresponding to the PLC Point if any of the alarming conditions is active at that point of time for the PLC. These alarms can be viewed in the Alarm Summary display of the Experion Station.



ATTENTION

If one or more alarms are raised at the status bit level of a Point, the OP parameter value of the Point is set ON and the corresponding alarm is raised at the PLC level.

Error indicating Alarms / Messages

The important system level error messages such as PLC connection errors are raised as System Alarms in Experion. The less important errors are logged as Messages. This includes errors such as errors in point configuration, and so on.

6. Alarms and Events integration

6.1. Alarm integration

The screenshot displays the 'Station - Default - Message Summary(sysMessageSummary.htm)' window. The interface includes a menu bar (Station, Edit, View, Control, Action, Configure, Help) and a toolbar with various icons. The main area is titled 'Messages' and shows a table of alarm messages. The table has columns for 'Date & Time', 'Location Tag', 'Source', and 'Message'. Three messages are listed, all from 'MLD1' at '17:56:28' on '7/25/2007', with the message text 'PLC: MLPLC1 Item Name: %WD0000\$CON#NT Invalid Data typ...'. A left-hand pane shows a tree view of 'System Components' with 'ML_SERVER (local s)' expanded. At the bottom, there are buttons for 'Pause', 'Resume', and 'Acknowledge Page', along with a status bar showing 'Unacknowledged messages: 3' and 'Acknowledged messages: 0'. A detailed view of a message is shown at the bottom of the page.

Date & Time	Location Tag	Source	Message
7/25/2007 17:56:28	ML_SERVER	MLD1	PLC: MLPLC1 Item Name: %WD0000\$CON#NT Invalid Data typ...
7/25/2007 17:56:28	ML_SERVER	MLD1	PLC: MLPLC1 Item Name: %WD0000\$CON#NT Invalid Data typ...
7/25/2007 17:56:28	ML_SERVER	MLD1	PLC: MLPLC1 Item Name: %WD0000\$CON#NT Invalid Data typ...

Unacknowledged messages: 3
Acknowledged messages: 0

Buttons: Pause, Resume, Acknowledge Page

Message Details:

Honeywell	25-Jul-07	17:56:36	Message	epkssvr1b	Strn01	Mngr
-----------	-----------	----------	---------	-----------	--------	------

Viewing PLC alarms in Experion Station

The Alarms are raised based on the present status of the PLC. A PLC level alarm is raised corresponding to the PLC Point if any of the alarming condition is active at that

6. Alarms and Events integration
6.1. Alarm integration

point of time for the PLC. These alarms are displayed in the Alarm Summary display in the Experion Station.

Sample alarms raised in Experion




Figure 6.1-1: Sample alarms in Experion

6.2 PLC Events

Types of PLC events

The PLCs record the following four different types of events:

Event Type	Description	Buffer Size in CPU
Error log	This log provides information about the errors generated during the operation. The error code, date, time and error details are saved in this file.	2048 events
Shutdown log	This log provides the time details of ON/OFF information of the system. The date, time and the ON/OFF state are saved in this file.	1024 events
Mode log	This saves the changed CPU mode information and time in case there is a change in mode of operation.	1024 events
System log	This saves the operation history of system events that occur during operation.	2048 events
DISOE	These are the sequence of events in the DISOE module captured by CPU.	3000 events

Transferring PLC events to Experion/Log files

The Experion Station can be used for viewing a summary of the events.

To transfer the PLC events to Experion/Log file, the parameters in the PLC Logs must be configured for each PLC using the MLServer Configuration Tool.

The following table lists the PLC Log parameters and their descriptions:

Parameter	Possible Values	Description
Initial History	Enabled/Disabled	<ul style="list-style-type: none"> If it is Enabled, the already existing PLC events are transferred to Experion server or Log files during startup of the MLServer based on the LogToFile and Events settings. If it is Disabled, backlog events are not transferred during the MLServer startup. However the events that occur when the MLServer is running are transferred to Experion server or Log files.
Log To File	Enabled/Disabled	If it is Enabled , the PLC events are transferred to log files. These log files are stored in the same folder path used for storing the MLServer log files.
Events	Enabled/Disabled	If it is Enabled , the PLC events are transferred to Experion server as System Events / Alarms.
ScanPeriod		It represents the interval in which the PLC log is scanned for changes and events are logged into the log file and /or Experion server. If this is 0 then the corresponding PLC log is not scanned for changes at all.

After the MLServer starts communicating with the PLCs, depending on the values of these parameters, the events are transferred to the Experion server or the Log files.

The backlog events are saved in the memory area of the respective PLCs. These events can be viewed in the SoftMaster, as shown in the following figure:

6. Alarms and Events integration
6.2. PLC Events

PLC history - NewPLC


Error Log Mode Log Shut down Log System Log

Index	Date	Time	Contents
84	2005-08-18	18:41:33.001	Data trace, Use
85	2005-08-18	18:43:32.865	Momently shut-down
86	2005-08-18	18:46:09.001	Data trace, Use
87	2005-08-18	18:57:16.181	USB, OK, Connect
88	2005-08-18	18:57:19.876	USB, OK, Disconnect
89	2005-08-18	18:57:23.541	USB, OK, Connect

After restarting the MLServer, these events are transferred to the Experion server or log files based on the PLC log parameters settings. To get the backlog of the PLC logs into Experion, the Initial history option could be enabled.

To view a summary of events select View > Events > Event Summary from the Experion Station Display. The following figure depicts the list of events viewed from the Experion Station:

The following figure depicts how the PLC events are transferred to Experion server and are saved in the log files:



Transferring SOE events from PLC to Experion Station



WARNING


Honeywell does not recommend modifying the Quick Builder database when MLServer is executing. After modifying QDB, please restart MLServer by disabling and enabling the MLchannel.

The Experion Station can be used for viewing a summary of the sequence of events generated in the PLC. To transfer the PLC events to Experion/Log file, perform the following steps.


Step	Action
1	Connect to PLC with DISOE module using SoftMaster.
2	In the I/O Parameter Setting dialog box, select the SOE module base and slot.
3	Configure the SOE module by selecting the type of events to be captured by the PLC, chattering time and others. In the I/O Parameter Setting dialog box, double-click the SOE module or click Details . The SOE Module dialog box appears.
4	Under SOE History , click Reset with recent history option button.

6. Alarms and Events integration
6.2. PLC Events

Step **Action**



- 5 In the **Basic Parameter Setting** dialog box, click **Save the latest SOE events** option button.



Step	Action
6	Ensure Write to PLC after changing these parameters.
7	In Quick Builder, configure a status point in the device area format.
8	Configure a PLC Point as ML01.U1.2.6\$DEV#BIT@SOE in Quick Builder and download to the Experion server. Note: The PLC point must be configured with U1.2.6, where 1 is Base No1, 2 is Slot no 2, and 4 for Channel no 4. Also, @SOE must be added to string at the end to indicate that the point is an SOE module point. You should not configure PLC point as ML01.U01.02.06\$DEV#BIT@SOE in Quick Builder.
	 ATTENTION All the SOE points must be configured with DEV command and #BIT type. Ensure that base number, slot number, and channel number does not preced with '0'.
9	Enable the Channel containing the configured PLC Point.
10	The SOE events are transferred to the Experion server SOE summary page.

7. Troubleshooting

7.1 MasterLogic Server logs

Overview

The MLServer has two modules, the ML Protocol and the MLServer. The modules generate a series of logs, which are useful for various troubleshooting, analysis and recording purposes.

The following is the list of logs generated by the ML Protocol and the MLServer:

- Activity
- Request
- Response
- Trace
- Error
- Hex
- MLMonitor

MLServer logs

The Parameters under **MLServerLogs** to enable/disable the generation of logs are selected using the MLServer configuration tool. The path to store the log files are also configured. The **LogFolderPath** parameter value indicates the path, where the MLServer logs are saved.



The following table explains the logs generated by the MLServer:

Log	Optional / Mandatory	Description
Activity	Mandatory	This log provides general information like MLServer initialization, thread start/stop and successful add item messages.

7. Troubleshooting

7.1. MasterLogic Server logs

Log	Optional / Mandatory	Description
Error	Mandatory	This log provides information about unsuccessful add item, exceptions and general error messages. The information in this log helps for troubleshooting.
Request	Optional	This log provides information about requests sent to the PLC by the MLServer. To generate this log, set RequestLog to Yes .
Response	Optional	This log provides information about responses received from the PLC by the MLServer. To generate this log, set ResponseLog to Yes .
Trace	Optional	This log provides detailed information that helps debugging. To generate this log, set TraceLog to Yes .
MLMonitor	Optional	This log provides information about the status of UDP writing to Experion, PLC status, base slot information, RTC, IP Address and alarms raised. To generate this log, set MLMonitorLog to Yes .

ML protocol logs

The parameters under **MLProtocol Logs** to enable/disable the generation of logs are selected using the MLServer Configuration tool. The path to store the log files is also configured.

The **LogFolderPath** parameter value indicates the path, where the ML protocol logs are stored.



The following table explains the logs generated by the ML protocol:

Log	Optional / Mandatory	Description
Activity	Mandatory	This log provides information on initial xml settings, socket connection/disconnection status.
Error	Mandatory	This log provides information on errors occurred during communication between the PLC and the MLServer and all exceptions.
Request	Optional	This log provides information on requests sent to the PLC by the MLServer. To generate this log, set RequestLog to Yes .
Response	Optional	This log provides information on responses received from the PLC. To generate this log, set ResponseLog to Yes .
Trace	Optional	This log provides detailed information that helps debugging. To generate this log, set TraceLog to Yes .
Hex	Optional	This log displays Hex dump packets sent to/received from the MLServer.



ATTENTION

The Activity and Error logs are mandatory and generated by default. These logs are not controlled by any parameter setting.

The optional log settings can be enabled or disabled at Runtime by changing the appropriate XML parameters. Any change for these configurations are updated every 30 seconds.

Honeywell

Honeywell Process Solutions
1860 W. Rose Garden Lane
Phoenix, AZ 85027 USA