



	<p>MODBUS-kit with pre-assembled screw and a 23 mm spacer.</p>
	<p>Unmount the screw, as the arrow points to, in your device.</p>
	<p>Replace the screw with the 23 mm spacer.</p>

	<p>Mount the 6 pole cabling by carefully pressing it into the socket named K3. Because of the locating lugs <u>the cabling only fits in the direction shown in the picture.</u></p>
	<p>Finally mount the MODBUS-card into the spacer. To fit in the housing, the card must be mounted upside down.</p>