70-82-03-03 11/07 Page 1 of 4

# 7773 Multipurpose pH/ORP Electrode Mountings

## **Specification**

#### Overview

The 7773 Mounting is available with the widest available electrode, preamplifier, automatic temperature compensator, and mounting assembly options. Capabilities include state-of-the-art ISFET technology with Honeywell Durafet II® electrode options. These truly solid state sensors feature exceptionally fast response and a low impedance signal right from the sensing element that is virtually unbreakable. An improved packaging design allows the Durafet II electrode to be used in a wide variety of process applications.

#### **Description**

Overall 7773 Mounting capabilities encompass the industrial measurements

of pH, ORP, specific ion, and temperature in a flow or submersion configuration. Wetted material choices include 316 stainless steel, glass-fiber reinforced polypropylene or Ryton® (Phillips Petroleum tradename for polyphenylene sulfide), for use in corrosive solutions at pressures up to 1034 kPa (150 psig) and temperatures up to 130°C (266°F). The 7773 is available in seven configurations; change between flow- and submersiontype mounting requires substitution of only one part.



#### **Features**

- Durafet II Ion Sensitive Field Effect Transistor (ISFET) Electrode options
- Universal mounting—most parts interchangeable between flow and submersion configurations.
- Widest range of electrode options
- Combined pH, ORP and temperature measurement options in one mounting with UDA2182 Analyzer
- Ultrasonic electrode cleaning options
- Corrosion-resistant polymer and 316 stainless steel housing with integral preamplifier
- FM approved for Class I, Div 1, Group A, B, C, D locations with APT Transmitter and barriers; suitable for Division 2 locations with UDA2182 analyzers
- NEMA 4X, IP65 watertight and corrosion-resistant flow, and NEMA 6, IP68 submersible ratings

#### **Preamplifier**

Housed within the 7773 Mounting, the preamplifier accepts input from electrodes and temperature compensator through a sealed connector and terminals. Preamplifier circuitry is hermetically sealed against moisture and electrically shielded by its metal enclosure. A unique guarded circuit protects the high impedance glass electrode input, providing a thousand-fold decrease in sensitivity to electrical leakage under the potentially dirty, humid conditions of actual usage. The amplified signal can be sent over ordinary unshielded wire in excess of 305 m (1000 ft.) to the Honeywell measuring instrument.

The Durafet II electrode cap adapter option provides quick disconnect at input and output.

#### 70-82-03-03 Page 2

Preamplifier systems have high immunity to ground loop noise and spurious RF signals. Grounded and ungrounded solutions can be measured. Lightning protection is included in all preamplifiers. This is important when the mounting will be in a location subject to frequent lightning activity. It provides substantial protection by dissipating moderately destructive surge currents through the electrodes but cannot prevent failure caused by very near strikes.

#### **Electrode Cleaning**

Unattended automatic fluid cleaning and calibration of electrodes used with Honeywell 9782 Analyzers can be provided.

A continuously operating ultrasonic cleaner is optional with the 7773 Mounting to reduce maintenance caused by fouling or coating of the electrodes and particulate matter. It is less effective with oily or other resilient coatings that tend to absorb ultrasonic energy.

The ultrasonic cleaner consists of a transducer that fits within the 7773 between the electrodes with an integral 9 m (30 ft.) cable that runs directly to the 120/240 Vac-powered, NEMA 4, wall-mounted generator. It may be specified in Table 1 as part of a new mounting or ordered as a retrofit kit with 316 stainless steel (Kit 31002466) wetted parts. Ultrasonic cleaning is not recommended for use with Durafet II II or antimony electrodes.

#### **Wetted Materials**

**Polypropylene** offers the advantage of a light weight, tough plastic with good chemical resistance at low cost. Polypropylene may be weakened by some organic solvents and chlorine but is recommended for all general-purpose applications.

**Ryton** (polyphenylene) provides excellent chemical resistance and higher temperature and pressure ratings than polypropylene at moderate cost. Ryton is somewhat brittle and does not tolerate rough handling.

**316 Stainless steel** offers ruggedness, and the highest pressure ratings.

#### pH, ORP Electrodes and Temperature Compensators

Durafet II II combination and measuring electrodes use the new ISFET (Ion Sensitive Field Effect Transistor) sensing element with especially fast response. Durafet II II sensors produce a low impedance pH signal for outstanding reliability even at low temperatures and they experience no sodium error or ORP interference. The combination Durafet II II electrode incorporates a reference electrode with replaceable KCI gel fill for long life.

All Durafet II II electrodes include an integral automatic temperature compensator for conventional Nernst electrode compensation. Because compensation is performed in the preamplifier, no separate compensator is used and no temperature display can be provided at the measuring instrument.

Conventional pH measuring electrodes used with the 7773 mountings are useable over a wide pH range. These sensitive, rugged electrodes have quick disconnect cable connections. Glass membrane formulations are available for a variety of temperature ranges. The 7773 mounting and UDA2182 are compatible with most 1/2" dia. ion-selective electrodes.

Reference electrodes are filled with a KCI slurry or a long-lasting viscous KCI gel. The gel is recommended for general-purpose use, especially for applications involving severe contamination, temperature or pressure cycling, continuous high temperatures, and dry periods. The Ryton electrode is virtually unbreakable and has an easily replaced porous-plug junction of ceramic. The glass body reference electrode has the porous plug sealed into the tube and the cap and internal element are removable for maintenance.

Meredian® Combination
Electrodes comprise a rugged,
virtually unbreakable, chemicallyresistant Ryton body with a sealed,
non-refillable long-lasting gel-type
KCI diffusion reference electrode and
a central element with a pH glass
membrane designed for durability.
The unique geometry of the annular
ceramic reference junction permits
making accurate, continuous pH
measurements in the presence of
high solution currents.

Automatic temperature compensators correct for the measuring electrode temperature coefficient. With microprocessor-based instruments they can also correct for the change in ionization of pure water samples, providing solution temperature compensation to 25°C. Temperature compensation is not used in ORP systems.

#### **Specifications**

				Specificat	10113				
			7773 Mc	ounting Specific	ations				
Application	pplication Flow service in moders pressurized lines or atmospheric discharge		Flow service in lines**	High-pressure	Submersion service in open tanks or process vessels. Submersion depth: up to 61 m (200 ft.) with preamplifier; up to 3m (10 ft.) without preamplifier				
Materials: Cover, Connecting Ring, Flow Chamber and Guard	Polypro- pylene	Ryton	316 SS	316 SS, with Polypro- pylene Cover**	Polypro- pylene	316 SS	Ryton		
Maximum Pressure and Temperature of Assembly only	689 kPa (10 psig), 60°C (140°F); 34 kPa (50 psi 80°C (176°I	psig), 80°C (176°F); 345 g) kPa (50 psig),	1034 kPa (150 psig), 80°C (176°F); 552 kPa (80 psig), 130°C (266°F) ****		689 kPa (100 psig), 60°C (140°F); 345 kPa (50 psig), 100°C (212°F)	689 kPa (100 psig), 80°C (176°F); 552 kPa (80 psig), 110°C (230°F)***			
Sample flow rate		(15 gpm) max. Lowe brasives and high-pu		scous	_				
Installation		it supplied for wall or nnections 3/4" NPT, fe		•	3/4" pipe support in tank (pipe not supplied). Use plastic pipe with plastic housing.				
Weight	1.4 kg (3 lb.	1.87 kg (4 lb.)	2.7 kg (6 lb.)	2.3 kg (5 lb.)	1.4 kg (3 lb.)	2.7 kg (6 lb.)	1.87 kg (4 lb.)		
** Conforms stability is *** If mountin cannot be	to A.P.I. and required. g is used abo located in manager of the provential maximum approval	rity water down to app ASME codes for 150 ve 110°C (230°F), electoring, specify 20 for imum pressure with 5 Usable at 100% R.F.	-psig operation. Fectrodes and tem r Table I and orde 16SS cover is 65	Recommended for sperature comperer an appropriate	or use in high-purnsator must be glepreamp module	ity water where ass-bodied and as a separate ite	preamp em.		
Electrode Supp	,	Ryton	1.						
Licelione Supp	OIL	Nyon							

Electrode Support	Ryton						
O-Rings	ton A is standard. Available in ethylene-propylene rubber (E.P.M.) Table IV = 301.						
O-Ring Washers	lypropylene (not in contact with sample).						
Compression Nut	Delrin (not in contact with sample).						
Dimensions	Approximately 102 mm OD x 279 mm long (4" x 11").						
Electrical Connections and Immersion Support Pipe	3/4" NPT female.						
Flectrode Specifications							

Electrode Specifications								
Part	Electrode	CONSTRUCTION			Temp.	Pressure	Electrode	
Number	Туре	Internal fill	Sensing tip	Body	Range	Limit	Termination	
51204976- 002	Durafet II pH Measuring Only (0-14 pH)	None	FET	Ryton	-10 to 110°C (14 to 230°F)	100 psig @ 110°C; 150 psig @ 80°C	Quick disconnect cable to electrode and preamplifier	
31117390	Glass pH Measuring— General Purpose	KCI & Buffer	glass	glass	10 to 80°C (50 to 176°F)	100 psig @ 110°C; 150 psig @ 80°C	Screw cap	
31117399	Antimony pH Measuring (2-11 pH range) recommended where fluorides are present below 5 pH	None	antimony	Ryton	5 to 75°C (41 to 167°F)	150 psig @ 75°C	Screw cap	
31117481	Reference—General Purpose, long life	KCI gel	repl. ceramic	Ryton	-5 to 110°C (23 to 230°F)	50 psig @ 110°C; 150 psig @ 60°C	6" wire; spade lug	
31035832	Reference (double- junction)—Sulfide- containing processes	NH <sub>4</sub> NO <sub>3</sub> gel	ceramic	Ryton	-5 to 110°C (23 to 230°F)	50 psig @ 110°C; 150 psig @ 60°C	6" wire; spade lug	
51204976- 001	Durafet II pH Combination; Meas. Ref. & temp. compensator (0- 14 pH)	KCI gel	FET	Ryton	-10 to 110°C (14 to 230°F)	100 psig @ 110°C; 150 psig @ 80°C	Quick disconnect cable to electrode and preamplifier	
31117486	Glass pH Combination; Meas. & Ref.—General Purpose	KCI gel	meas.: glass Ref.: ceramic	Ryton	10 to 100°C (50 to 212°F)	30 psig @ 100°C; 100 psig @ 60°C	Screw cap	
31020751	ORP Combination: Meas. & Ref.—for Chrome treatment	KCI gel	meas.: glass Ref.: ceramic	Ryton	-5 to 130°C (23 to 266°F)	30 psig @ 100°C; 100 psig @ 60°C	12' cable; tinned	

#### 70-82-03-03 Page 4

Electrode Specifications								
Part	Electrode	CONSTRUCTION			Temp.	Pressure	Electrode	
Number	Туре	Internal fill	Sensing tip	Body	Range	Limit	Termination	
31020749	ORP Combination; Meas. & Ref.—for Chrome or Cyanide treatment	KCI gel	meas.: gold Ref.: ceramic	Ryton	-5 to 100°C (23 to 212°F)	30 psig @ 100°C; 100 psig @ 60°C	12' cable; tinned	
31152137	Auto. Temperature Compensator—Use with Honeywell analog-based inst., 721 ohms at 25°C	None	None	Ryton	-5 to 110°C (23 to 230°F)	150 psig @ 110°C	6" 2-wire; spade lugs	
31022289	Auto. Temperature Compensator—Use with Honeywell microprocessor-based inst., 8550 ohms at 25°C	None	None	Ryton	-5 to 110°C (23 to 230°F)	150 psig @ 110°C	6" 2-wire; spade lugs	

Distributor:			

For more information, contact Honeywell sales at 1-800-343-0228.

### Honeywell

#### **Honeywell Process Control**

Honeywell 512 Virginia Drive Fort Washington, PA 19034