V		ALA Ind Temperature Probe HMP7 midity, with probe warming	Probe type	Probe cable	Sensor type	Filter type	Sensor purge	Baud rate	Parity, Data bit, Stop	Modbus address	Reserved	Installation accesso	<b>Connection cable</b>
	Order code	НМРХ НМ	 <u>م</u> 7	₫.	s I	ш	S		<u> </u>	2	<u>22</u>	<u>–</u>	$\frac{\circ}{1}$
1	Probe type		1								U		+
		HMP7 for high humidity	7										
2	Probe cable		<u> </u>										
		2m cable		Е									
		10m cable		F									
3	Sensor type				1								
		Humicap R2 composite sensor, allows sensor purge			1								
		Catalytic composite sensor, allows sensor purge			3								
4	Filter type					1							
		Sintered stainless steel filter				в							
		Membrane SST filter for fuel cell applications				Е							
5	Sensor pure	ge, default purge interval 24h					4						
	1)2)	Probe heat on, purge on. Dew point measurement only					2						
6	Baud rate												
	2)	19200 bps						Α					
		9600 bps						В					
7	Parity, Data	bit, Stop bit							_				
	2)	8, N, 2							0				
		8, E, 1							2				
		8, 0, 1							4				
8	Modbus add	dress											
	2)	240								Α			
		110								В			
		120								С			
		130								D			
9	Reserved												
		None									0		
10	Installation	-										_	
		None										0	
		Duct installation kit										В	
		Cable gland with split seal; for sealing the probe from the cable										С	
		Swagelok for NPT 1/2" thread										G	
		Swagelok for ISO 3/8" thread										H	
		Swagelok for ISO 1/2" thread										J	
4.4		Splash protector for warmed HMP7										Κ	l
11	Connection												~
		None											0
		1.5m with flying leads											1
1		10m, with flying leads be heating is activated, dew point temperature, mixing ratio and wate											2

 When probe heating is activated, dew point temperature, mixing ratio and water mass fraction are availa For RH, T and other variables, compensation temperature has to be set through the Modbus interface
Factory pre-set, can be changed in the field with a service cable (P/N 242659)

Probe can be connected to INDIGO series of transmitters regardless of the output configuration.

## Selections in bold are included in the prices of the basic versions.

Selections in italic are available at an extra price.

Example of order code with typical settings:

For use with INDIGO transmitters	HMPX	7	Ε	2	Α	6	Α	0	Α	0	0	0
For use with Modbus RTU	HMPX	7	Ε	2	Α	6	Α	0	Α	0	0	2